

VCM-X Controller Code: SS1026 & Y200920 Version 2.0 and up; VCM-X Modular Controller Code: SS1030 & SS1034 VCM-X WSHP Controller Code: SS1032 & SS1033 SA Controller Code: Y200921 VCM Controller Code: SS1016, Y200409, Y200616, Y200822



# **Table of Contents**

General Information	3
Data Sharing	3
Scheduling	3
Hardware Specifications	3
System Requirements	3
Dimensions and Components	4
Quick Guide	4
Connection and Wiring Information	5
Configuring the PT-Link II Controller	6
PT-Link II Hardware Connection	6
Computer IP Address Set-up for Windows NT & XP	7
Computer IP Address Set-up for Windows Vista & 7	8
Connecting to the PT-Link II	9
Making Changes to the Configuration File (config.csv)	10
Downloading Config.csv to the PT-Link II	11
Troubleshooting the PT-Link II Controller	13
Addressing WattMaster Devices in a BACnet® Network.	13
PT-Link II Board LEDs.	14
ProtoCessor Module LEDs	15
Troubleshooting Using RUINET	16
Verifying Proper Communications	16
Verifying Proper Values	16
Updating the PT-Link II Controller	17
Data Arrays	21
Table 2: VCM-X Modular Data Array for Field Server	21
Table 3: VCM-X WSHP (Tulsa) Data Array for Field Server	21
Table 4: VCM-X WSHP (Coil) Data Array for Field Server	22
Table 5: VCM-X Data Array for Field Server	22
Table 6: SA Controller Data Array for Field Server	23
Table 7: VCM Data Array For Field Server	23
Appendix A	24
Figure 25: RJ-45 8P8C Cable for WattMaster Cross Over Networking - WattMaster Part #HZ000136	24
Appendix B	25
ProtoCessor Driver - (PICS) BACnet Protocol Implementation Conformance Statement	25
Appendix C - VCM-X Modular and VCM-X WSHP BACnet Parameters	26
	20
Appendix D - VCM-X BACnet Parameters	28
Appendix E - SA Controller BACnet Parameters	34
Appendix F - VCM BACnet Parameters	38

WattMaster Controls, Inc. 8500 NW River Park Drive · Parkville, MO 64152 Toll Free Phone: 866-918-1100 PH: (816) 505-1100 · FAX: (816) 505-1101 · E-mail: mail@wattmaster.com Visit our web site at www.orioncontrols.com Form: OR-PTLNK-II-BACNET-TGD-01D Copyright August 2011 WattMaster Controls, Inc. BACnet<sup>®</sup> is a registered trademark of ASHRAE Inc., Atlanta, GA. WattMaster Controls, Inc. assumes no responsibility for errors or omissions. This document is subject to change without notice. The OE368-23-BACNET, PT-Link II BACnet<sup>®</sup> provides bi-directional communication between your BACnet<sup>®</sup> MS/TP protocol network and up to four\* of any of the following types of Orion controllers—VCM-X, SA, VCM, MUA II, or VAV/CAV:

VCM-X Controller (SS1026, SS1030, SS1032, SS1033, SS1034, Y200920)

SA Controller (Y200921)

VCM Controller (SS1016, Y200409, Y200616, Y200822)

\*\*MUA II Controller (Y200405); VAV/CAV Controller (Y200301)

To determine what controller you have, you must look at the label located on the controller EPROM. If the controller label does not match any of the SS or Y numbers listed above, your controller will not work with the PT-Link-BACnet<sup>®</sup>.

\*NOTE: The PT-Link II BACnet<sup>®</sup> device can be used to connect to four Orion controllers. If more than four Orion controllers are present in a system, you will need one or more additional PT-Link II BACnet<sup>®</sup> devices for integration with a BACnet<sup>®</sup> protocol network.

\*\*NOTE: Documentation is available for MUA II/VAV/CAV on our Orion Controls website: www.orioncontrols.com/ literature-new.html

### Scheduling

 Ability to allow BACnet<sup>®</sup> devices to send Schedule events to the Orion controller side of the gateway by using standard BACnet<sup>®</sup> services.

### **Hardware Specifications**

**Table 1** contains the hardware specifications for the PT-Link II BACnet<sup>®</sup> interface.

Technical Data	
BACnet®-MS/TP Loop	9600, 19200, 38400, 76800 Mbps
Controller Loop	RS-485, 9600 Baud Rate
Network Protocol	BACnet®
Protocol (WattMaster Loop)	HSI Open Protocol Token Passing
Power Input Voltage	24 VAC
Power Consumption	10 VA Maximum
Operating Temp	-30°F to 150°F
Operating Humidity	90% RH Non-Condensing
Weight	4.5 oz.

 Table 1: PT-Link II BACnet<sup>®</sup> Interface Technical

 Data

## Data Sharing

The PT-Link II BACnet<sup>®</sup> interface provides the following data sharing capabilities:

- Provides values from points on the Orion side of the gateway to BACnet<sup>®</sup> devices as if the values were originating from BACnet<sup>®</sup> objects.
- Allows BACnet<sup>®</sup> devices to modify point values on the Orion controller side of the PT-Link-BACnet<sup>®</sup> by using standard BACnet<sup>®</sup> write services.

### System Requirements

- The PT-Link II BACnet<sup>®</sup> interface is packaged and assembled as surface mount. Surface mount components are included for your convenience.
- Computer running Microsoft Windows<sup>TM</sup> operating system.
- Ethernet Crossover Cable (supplied).
- PT-Link BACnet software—located on included CD-ROM and downloadable from www.orioncontrols.com/software-new.html.
- RUINET software— located on included CD-ROM and downloadable from www.orioncontrols.com/software-new. html

# Setting Up Your PT-Link II

### **Quick Guide**

The following steps will be get you up and running in no time:

- 1. Familiarize yourself with the PT-Link II components (Figure 1).
- 2. Connect your PT-Link II to the Controller(s) on your system (up to four) and connect your PT-Link II to the BACnet Network (**Figure 2**).
- Copy the contents of the PT Link II CD to your PC's Desktop. You can also download the files from http://orioncontrols.com/ software-new.html under PT-Link II Setup Files. These files include RUINET.

- 4. Connect your PT-Link II to your computer using an Ethernet connection (**Figures 3 & 4**).
- Change your PCs IP Address. Follow the directions that match your current operating system - Windows NT, XP, Vista, or 7. See directions on pages 7 & 8.
- 6. Obtain the following from your Building Automation System Integrator: the BACnet MAC address (System Node ID), your server's baud rate, and the Client Node ID.
- 7. Using RUINET, edit the Config.csv file and verify PT Link II communications. Follow the directions on **pages 9-12**.
- 8. If you run into any problems, follow the instructions in the Troubleshooting section starting on **page 13** of this guide.



Figure 1: PT-Link II BACnet® Dimensions and Components

### **Connection and Wiring Information**



### Figure 2: PT-Link II BACnet® Interface Wiring

# **PT-Link II Ethernet Connection**

### **PT-Link II Hardware Connection**

You have two options for connecting the PT-Link II to your PC via Ethernet:

- 1.) You may connect the PT-Link II directly to your PC by using a crossover cable (by others) as shown. **See Figure 3** for details.
- You can also connect both your PC and the PT-Link II to an Ethernet Hub with standard CAT5 cables. See Figure 4 for details.

Locate a CAT5 cable and plug one end into your computer's Ethernet port (use a crossover cable if connecting directly to the PT-Link II). If connecting directly, plug the other end of the Cable into the Ethernet port on the PT-Link II. If connecting through an Ethernet Hub, plug the other end of the PC cable into the hub, and use a second CAT5 cable to connect the PT-Link II to the hub as well.

Power up the PT-Link II by plugging in the power cable. The PT-Link II may take up to three minutes to power up completely. Once the PT-Link II is powered up, you should notice that the "**GPI05**" LED light on the ProtoCessor Board remains on continuously. **See Figure 21** for a diagram showing the location of the ProtoCessor "**GPI05**" LED.



Figure 3: Connecting With Crossover Cable

### **IP Address Configuration**

### Computer IP Address Set-up for Windows XP, Vista, and 7

In order for the PT-Link II to communicate properly, it is imperative to set the IP address of both the PT-Link II as well as the computer to be within the same netmask. You need to change the IP address on your computer. The following instructions will explain how to configure the IP address for Microsoft<sup>®</sup> Windows XP, Vista, and 7 operating systems.

# Computer IP Address Set-up for Windows NT & XP

- 1.) Click <start>; then click <Control Panel>.
- 2.) *Double-click* on the **Network Connections** icon.
- The Network Connections Window will appear (Figure 5).



Figure 5: Network Connections Window

- **NOTE:** If any wireless connections are listed, disable them by *right-clicking* the connection and *selecting* **<Disable>**.
  - In the Network Connections Window, double-click the Local Area Connections entry. The Local Area Connection Status Window will appear (Figure 6).

🕹 Local Area Co	nnection Status	? 🔀
General Support		
Connection		
Status:		Connected
Duration:		01:30:28
Speed:		100.0 Mbps
Activity	Sent — 🕎	- Received
Bytes:	5,064,596	14,942,743
Properties	Disable	
		Close

#### Figure 6: Local Area Connection Status Window

4.) As shown in **Figure 6**, *click* **<Properties>** in the lower left of the window. The *Local Area Connection Properties Window* will appear.

🗕 Local Area Connection Properties 🛛 🔹 💽					
General Authentication Advanced					
Connect using:					
Marvell Yukon Gigabit Ethernet 10/1 Configure					
This connection uses the following items:					
Client for Microsoft Networks  Element for Microsoft Networks  Element Scheduler  Action of CTCP/IP)					
Install Uninstall Properties Description Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.					
<ul> <li>Show icon in notification area when connected</li> <li>✓ Notify me when this connection has limited or no connectivity</li> </ul>					
OK Cancel					

#### Figure 7: Local Area Connection Properties Window

5). As shown in **Figure 7**, in the Connection Items list box, be sure the **Internet Protocol (TCP/IP)** is checked. *Select* the **Internet Protocol (TCP/IP)** item to highlight it and then *click* **<Properties>**. The *Internet Protocol Properties Window* will appear.

# **IP Address Configuration**

'ou can get IP settings assigne nis capability. Otherwise, you ne ne appropriate IP settings.	d automatically if your network supports eed to ask your network administrator fo
Obtain an IP address autor	natically
Ose the following IP address	ss:
IP address:	192.168.1.5
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	
Obtain DNS server addres:	automatically
Output the following DNS service	ver addresses:
Preferred DNS server:	
Alternate DNS server:	· · ·
	Advanced.

#### Figure 8: Internet Protocol Properties Window

- 6). *Select* the radio button in front of **Use the following IP address (Figure 8)** and *write down* the current defaults so that you can re-enter them when you finish configuring the PT-Link and then *type in* the following information:
  - a.) IP address 192.168.1.5
  - b.) Subnet mask 255.255.255.0
  - c.) Default Gateway is blank

7.) *Click* **<OK>** until all of the above network configuration windows are closed. You may have to *reboot* the computer before the new values are valid.

# Computer IP Address Set-up for Windows Vista & 7

- 1.) Click <start>; then click <Control Panel>.
- 2.) *Click* on the **Network and Internet** icon.
- 3.) Click Network and Sharing Center.

4.) From the shaded box in the left side of the window, select **Manage Network Connections** (Vista) or **Change adapter settings** (Windows 7).

5.) *Right-click* on the **Local Area Connection** icon and *select* **<Properties>** for the drop down window.

6.) *Choose* **Internet Protocol Version 4 (TCP/IPv4)** by highlighting it and then *click* **<Properties>**. The *Internet Protocol Properties Window* will appear (**Figure 8**).

- Select the radio button in front of Use the following
   IP address (Figure 8) and write down the current defaults so that you can re-enter them when you finish configuring the PT-Link and then type *in* the following information:
  - a.) IP address 192.168.1.5
  - b.) Subnet mask 255.255.255.0
  - c.) Default Gateway is blank

9.) *Click* **<OK>** until all of the above network configuration windows are closed. You may have to *reboot* the computer before the new values are valid.

# **Running RUINET**

### **Connecting To The PT-Link II**

1.) In order to communicate and program the PT-Link II you will need to install RUINET software on your computer. If you do not have the software, it is available for downloading at www.orioncontrols.com/software-new.html under PT-Link II Software

**WARNING:** Make sure to load RUINET onto your hard drive and run the program from your hard drive. DO NOT under any circumstances run RUINET from your cd drive.

2.) If RUINET is in the desktop directory (if it isn't, locate its directory), double-click on RUINET, and the RUINET program should run. Initially, you might see the screen below (**Figure 9**). *Type* **<I>** for Specify IP Address and the message "Enter IP Address of the Field Server to Connect to" will appear on the screen.



### Figure 9: RUINET PT-Link Specify IP Address

3.) Type the IP Address of <192.168.1.24> and press <Enter>.

4.) If you have only one PT-Link connected to the network, then RUI-NET will automatically connect to that particular PT-Link; otherwise, a menu will appear to allow the selection of the desired PT-Link.

NOTE: If RUINET is unable to establish a connection, there are a few simple procedures you can perform to try to determine the problem. To verify your network cables, observe the green LED displayed directly above and to the right of the Ethernet port. This LED should be on if the 10 BaseT cable is good. Secondly, observe the red LED displayed directly above and to the left of the Ethernet port. This LED should be solid while RUINET is running. If the LEDs are lit as expected, and RUINET still does not receive replies, then the netmask is probably incorrect. If this does not help, then your Ethernet setup on your PC is possibly not compatible. Ensure that you have an Ethernet adapter installed in your software configuration and that it is configured to run the TCP/IP protocol. If you are still unable to connect, please contact WattMaster Controls.

5.) On subsequent connections, a list of PT-Links that have been recently connected may appear under the message "Recently connected to FieldServers. Select the required PT-Link by *typing* the Number or Letter in the left hand column. (Figure 10).

🖾 Command Promp	_ □ ×
FieldServers discovered on the network 1 Testing Modbus 2 Toolkit Pro Server	192.168.8.45Type "1" to pick the first192.168.8.252FieldServer or "2" to pick the second.
Recently connected to FieldServers	
A No_Title_Assigned B Toolkit Pro Server	192.168.0.45 192.168.0.252
<pre>(n/nn&gt; Select a FieldServer to connect t Specify &lt;1&gt;P Address <c>lear Recent Fie</c></pre>	to (PgDn) Next Page (PgUp) Preu Page eldServers List (R)efresh list (Q)uit

#### Figure 10: RUINET PT-Link Selection Menu

6.) Once connected, you will see the *RUINET Main Menu* (Figure 11). Unless you need to make changes to the config.csv file (steps 7 through 15), you are now ready to send and receive files to and from the PT-Link.

Command Prompt - ruinet	_ 🗆 ×
Toolkit Pro Server B - FieldServer Information O - Connection Overview N - Mode Overview M - Map Descriptor Overview A - Data Array Overview F - Susten Fryngs	FieldServer Name. (Specified in 'FieldServer, Title' section of the CSV file).
F - Driver Messages D - Download Configuration to FieldServer U - Upload Configuration from FieldServer	to select the option.
I – Change IP Address K – Change UI Display Mode ! – Restart FieldServer	List of other action keys. Some of these keys only work in Expert Mode. Read the Advanced Notes on Tiers.
Keys: Type Appropriate Key for Selection (Q)uit (+) Next (+) Prev (Ctrl+) Last (Ctrl	*> First (n) Goto



# Changing the Config.csv File

7.) *Type* the letter **<U>** to upload the Config file (**Figure 12**), then *type* **<U>** again (**Figure 13**) for Upload.



Figure 12: RUINET PT-Link Main Menu - Upload



#### Figure 13: RUINET PT-Link Upload

8.) You will get confirmation that the upload is complete. *Type* <N> to open the file in Notepad.

**WARNING:** Only edit the config.csv file using Notepad. **DO NOT** use Excel. Using Excel to edit the config.csv file will corrupt its contents!

9.) Inside the text file you can change the System\_Node\_ID (the BACnet MAC address) which defaults to 11 (**Figure 14**). You can obtain this information from your Building Automation System (BAS) Integrator.

TextPad - C:\Documents and Settings\MikeB\Desk	top\PT Link Apps\BACnet\config.csv 🛛 🗐 🔀
Eile Edit Search View Tools Macros Configure	<u>W</u> indow <u>H</u> elp
10 <b>2888868</b>	☶  큰 ¶   🌒 🂖 🏭 👰 🗬 🖓 🕢 → 📮
config.csv	<b>▼</b> X
// // System_Node_ID	<b>^</b>
// For BACnet_MSTP the System_Node	e_ID is used as the MAC address.
Bridge TitleSystem_Node_ID Wattmaster MSTP v1.00f _11	
//=	
// Data Arrays	M
For Help, press F1	32 27 Read Ovr Block Sync Rec 💥

### Figure 14: Changing the BACnet MAC address

10.) If the server baud rate needs to be changed, go to the 'Connections' section and only change the SERVER\_BAUD (Figure 15). Possible Baud Rate values are (9600, 19200, 38400, 76800). The default Baud Rate is 38400. You can obtain this information from your BAS Integrator.

i read da crave americo ana vertina	gs\MikeB\Desktop\PT Link Apps\BACnet\config.csv 📃	
Eile Edit Search View Tools Macro	os <u>⊆</u> onfigure <u>Wi</u> ndow <u>H</u> elp	
10 <b>2 2 1 8 4 6 6 6 1 % 1</b> 6 6	비오 오   킅 큐   곧 ¶   🌒 🎔 អ 🕺 👁 🖗 🔹 🗰 🛛	-
config.csv		* ×
		^
eout becomes an official err	ror.	
Auto_Config_Server_,Server_0 BACnet-mstp5	Dbject_ID_Style ,Virtual_Server_Nodes ,Server_Ba ,No ,88400	ud
Auto_Config_Server_,Server_0 BACnet-mstp5 	Dbject_ID_Style ,Virtual_Server_Nodes ,Server_Ba .No	ud V

Figure 15: Changing the Baud Rate in Notepad

## Changing the Config.csv File

11.) The last change you may need to make is the Node\_ID under 'Client Side Nodes' which is the BACnet Device Instance Number (**Figure 16**). The default is 1. You can obtain this information from your BAS Integrator.

📱 TextPad - C: Wocuments and Settings WikeB Wesktop V	PT Link Apps\BACnet\config.csv 🛛 🗐 🛛
Eile Edit Search View Tools Macros Configure Windo	ow <u>H</u> elp
10 2 9 8 8 8 8 8 8 9 9 9 F	a 📲 🕼 🕲 🖗 🕼 🖉 🖓 🙀 🔹 🗤 🕨 🚽
config.csv	▼ X
// Client Side Nodes // Client Node_ID is used when virtual server side nodes are crea // The driver adds the Node_ID to the // class to make a server node_ID.	ated for MSTP and MN2 s instance number of each
Nodes Node_Name_Node_ID_Protocol_Port NODE_011WattMstr_S1	
	×
For Help, press F1	160 13 Read Ovr Block Sync Rec 🛒

Figure 16: Changing the Node ID in Notepad

12.) Once the changes are made to the text file, *click* **<File>** in the upper left and then *click* **<Save>**. Now close the file and return to the *RUINET Main Menu*.

13.) From the *RUINET Main Menu*, *type* **<D>** to Download the new config.csv file to the FieldServer (**Figure 17**).



Figure 17: Download new Config.csv file

14.) At the next screen, (Figure 18), type **<D>** again.



- **NOTE:** The utility will indicate when downloading is complete. **DO NOT** reset the PT-Link until this message is displayed, as this will corrupt the PT-Link.
- **NOTE:** The Remote Filename option must always be named "**config.csv**" for configurations; otherwise, it will be ignored by the PT-Link.

15.) Once the download is complete, *restart* the PT-Link II by cycling power or *press* **<Esc>** to get back to the *RUINET Main Menu* and then *type* **<!>** option to save the new configuration file and restart RUINET. It is possible to do multiple downloads to the PT-Link II before resetting it. There will be a start-up period where you will be unable to connect to the PT Link.

16.) From the *RUINET Main Menu*, *type* **<A>** for the Data Array Overview. The *Data Array Overview Screen* will display (**Figure 19**).

# **Verifying PT-Link Communications**

💌 C:	Documents and Sett	ings\MikeB\Desktop\ruin	et.exe	- 🗆 ×
		Data Arra	y Overview	·
	Data Array Name	Data Format Leng	th Data Age	
01- 02- 03-	WattMstr-Dump WattMstr-Stats DA_C162_I0	UInt16 20 UInt32 5 Float 10	00 2:09:10.850s 00 2:06:25.080s 0.020s 0.020s	
Ke ys :	: <r>eset &lt; <nn> Goto Data</nn></r>	Page Down> Next Pa Array OR <g>oto D</g>	ge (Page Up) Previous Pag ata Array	re <esc></esc>

Figure 19: Data Array Overview Screen

17.) This screen (**Figure 19**) will verify communication to the HVAC units. Lines 1 & 2 should always be present. After a start-up period of approximately 4 minutes, you will see 1 additional line for each HVAC unit. This screen represents the PT Link II communicating with 1 HVAC unit.

18.) Once these steps have been completed and you have verified that the reconfigured PT Link II has established communication to the HVAC unit(s), it can now be added to the BAS network.

## **Troubleshooting the PT-Link Controller**

# Addressing WattMaster Devices in a BACnet<sup>®</sup> Network.

Each PT-Link II BACnet<sup>®</sup> generates only one BACnet<sup>®</sup> device regardless of the number of WattMaster controls connected to it. This device will have all the properties of all the WattMaster controls connected. The instance of the device is equal to the unit address. The properties of each control can be differentiated by an offset of 500.

#### Examples:

- 1.) Properties of the controller address as 1 will range from 0 to 499.
- 2.) Properties of the controller address as 2 will range from 500 to 999.
- 3.) Properties of the controller address as 3 will range from 1000 to 1499.

To search for the instance of a specific property, follow the next formula:

**Property Instance** = ((Controller Address - 1) \* 500) + Instance Number from table.

#### Example:

- 1.) The PT-Link II BACnet<sup>®</sup> has a Node ID equal to five.
- 2.) Two VCM controllers connected and addressed to one and four.
- 3.) Searching for the Outdoor Temperature of each controller.
- 4.) Instance of the Outdoor Temperature in the VCM table equal to AI: 54.
- 5.) Client will only see Device 5.
- 6.) Under Device 5 it will see AI: 54 for the Outdoor Temperature of the unit addressed as 1 and AI: 1554 for the Outdoor Temperature of the unit addressed as 4.

**NOTE:** To simplify the calculation, we recommend that the WattMaster controllers be addressed in sequential order from one to the last controller without any unused address(es) in between.

# **Troubleshooting the PT-Link II Controller**

### **PT-Link II Board LEDs**

The PT-Link II BACnet<sup>®</sup> is equipped with LEDs that can be used for troubleshooting. There are eight LEDs on the PT-Link board. **See Figure 20** for the locations of the LEDs on the PT-Link board. The LED descriptions and functions are listed in the following paragraphs.

### POWER LED

When the PT-Link II BACnet<sup>®</sup> is powered up, the "**POWER**" LED should light up and stay on continuously. If it does not light up, check to be sure that you have 24 VAC connected to the board, that the wiring connections are tight, and that they are wired for correct polarity. The 24 VAC power must be connected so that all ground wires remain common. If after making all these checks the "**POWER**" LED still does not light up, please contact WattMaster Controls Technical Support at our Toll Free number—866-918-1100—for assistance.

#### LOOP LED

When power is applied to the PT-Link II BACnet<sup>®</sup>, the "**LOOP**" LED will also light up. The LED should flicker rapidly, indicating that the PT-Link is trying to communicate with the controllers on the loop. A "**flicker**" is defined as a brief moment when the LED turns off and back on. If the "**LOOP**" LED does not operate as indicated above, first power down the unit and then reapply power. If this does not work, please contact WattMaster Controls Technical Support at our Toll Free number—866-918-1100—for assistance.

#### LED 1

When power is first applied, "**LED 1**" will be off temporarily and then will blink one time for each controller it is communicating with. For example, if you have 4 controllers on the loop connected to the PT-Link, "**LED 1**" will blink 4 times. If the amount of blinks does not match the number of controllers connected to the loop, it indicates there is a communicating is to go to each controller and look at its "**COMM**" LED. The "**COMM**" LED should be solid and will flicker occasionally indicating communication with the PT-Link II BACnet<sup>®</sup>. If the "**COMM**" LED does not flicker, there is no communication with that controller.

#### LED 2

When power is first applied, "**LED 2**" will be off temporarily and then will blink slowly indicating that the PT-Link baseboard is communicating with the ProtoCessor Module. If "**LED 2**" does not blink, check that the ProtoCessor Module is installed correctly on the PT-Link baseboard and that the "**PWR**" LED is lit up on the ProtoCessor Module.

#### **PROTO LED**

When the PT-Link II is first powered up, the "**PROTO**" LED should light up and blink continuously. This LED verifies communication with the board and the ProtoCessor. If the LED doesn't light up, check that the ProtoCessor is installed correctly and firmly connected to the Base Board. The "**PWR**" LED should also be lit on the ProtoCessor Module.

#### TIMER LED

The "**TIMER**" LED is used for troubleshooting by WattMaster Controls Technical Support. The "**TIMER**" LED should always be blinking steadily.



#### Figure 20: PT-Link II BACNET® LED Locations

#### WATCH DOG LED

The "**W-DOG**" LED is used for troubleshooting by WattMaster Controls Technical Support. The "**W-DOG**" LED should always be on solid.

#### HEARTBEAT LED

The "**H-BEAT**" LED blinks to show the PT-Link II board software is running. If the LED doesn't light up, and all other checks have been made, please contact WattMaster Controls Technical Support at our Toll Free number—866-918-1100—for assistance.

# **Troubleshooting the PT-Link II Controller**

### ProtoCessor Module LEDs

#### **PWR LED**

When the PT-Link II is first powered up, the "**PWR**" LED should light up and stay on continuously. **See Figure 21**. If the LED doesn't light up, check that the ProtoCessor is installed correctly and firmly connected to the Base Board.

#### **GPI05 LED**

The "**GPI05**" LED will light up when the Base Board and the ProtoCessor Module have established communications. **See Figure 21**. This can take up to 3 minutes depending on the number of units connected to the PT-Link II. If it fails to light up after 3 minutes, check that the ProtoCessor is installed correctly and firmly to the Base Board.

#### LB LED

Once the unit is powered up, the "**LB**" LED must be blinking constantly. **See Figure 21**. If this LED is constantly on or off, the Module is not working properly and needs to be replaced.

#### LA LED

Once the unit is powered up, the "LA" LED must be blinking constantly. See Figure 21. If this LED is constantly on or off, the Module is not working properly and needs to be replaced.

#### TX & RX LEDs

The "**TX**" and "**RX**" LEDs work together to indicate that communication is being established with the desired protocol network. If both LEDs are blinking, then communication is working properly. **See Figure 21.** If not, check the protocol network wiring and the baud rate in the configuration file.

### D14 & D15 LEDs

The "D14" and "D15" LEDs work together to indicate that communication is being transmitted and received from the USB Port when performing an update to the PT-Link software.

If all of these tests are made and the controller still doesn't operate, please contact WattMaster Controls Technical Support at our Toll Free number—866-918-1100—for assistance.



Figure 21: PT-Link II BACNET® LED Locations

# Troubleshooting the PT-Link II Controller

### **Using RUINET**

Before continuing with the troubleshooting, make sure the PT-Link is connected correctly and the RUINET software is installed, running, and functioning correctly.

## **Verifying Proper Communications**

From the *RUINET Main Screen*, *press* **<O>** to go the *Connection Overview Screen*. This screen supplies information on communication between the PT-Link and remote devices. A number of aspect screens are available, and some of the aspect screens have more than one page. Use the space bar to toggle between aspects and use the **<PgUp>** and **<PgDn>** keys to toggle between pages of the same aspect. The *Connection Overview and Settings Aspect Screen* is shown in **Figure 22**.

The main purpose in this screen is to verify that messages and characters are being transmitted and received. In addition, it shows the number of communication errors. If the PT-Link connection "03" is the protocol connection, verify that is communicating appropriately. If it is not, check that the PT-Link LEDs are working properly, the unit is wired correctly, and the PT-Link is configured correctly (Baud Rate, Unit Address & MAC Address). If the number of errors is constantly increasing, move to the *Error Screen* by *pressing* the **Space Bar>** 3 times to find out the cause of the errors. Use the **Space Bar>** and **Space** between pages of the *Error Screen*.

## **Verifying Proper Values**

To verify that the correct values for each unit are being communicated to the PT-Link, move to the *Data Array Overview Screen*. To get to the screen, *press* **<A>** from the *RUINET Main Menu*. See Figure 23 for screen details.

In the *Data Array Overview Screen* (Figure 23) you will be able to see the data arrays of all the units connected to the PT-Link denoted by an array name "DA\_XXX\_IY"—Y being the address of the unit minus one. The Address of the unit is determined by a set of dip switches. To view the values being communicated from a specific unit, move to the *Data Array Detail Screen* (Figure 24) of the unit by entering the number under which it is listed. For example, for the unit listed in the third position, *enter* <03>.

To understand what each value means, look at the Data Array Tables for the desired unit type, VCM-X, SA, or VCM. You can change the writable values from this screen by using the modify command. To use the modify command, *press* **<M>** from the *Data Array Detail Screen* and then *enter* the Offset you want to change followed by a space and the new value.

*Example:* To change the Cooling Supply Setpoint to 60 in the VCM, *press* **<M>**, *enter* **<58 60>**, and then *press* **<Enter>**. This could be useful to prove that the unit can take and keep the setpoints properly.











## Updating the PT-Link II Controller

# Programming the PT-Link II with BootLoader

The PT-Link II is equipped with the ability to update its software with the use of a computer. You will need the following before you begin:

- PT-Link II in need of an update (powered up, no other connections necessary)
- Computer running Microsoft Windows<sup>TM</sup> operating system
- Prism II software from www.orioncontrols.com/softwarenew.html
- Latest version of PT-Link II software (e-mailed from our tech support staff or downloaded from any of our websites) and software sheet
- USB Driver Setup.exe file from PT-Link II CD or downloaded from any of our websites.
- USB cable

#### Follow these simple steps to update the PT-Link II:

1.) Turn on your computer and download the latest Prism II software from www.orioncontrols.com/software-new.html.

2.) Either download the PT-Link II update file from http://techsupport. wattmaster.com or save the file to your computer from the e-mail you received from Tech Support. Record the path and name of the file for later use. Also, print the software sheet provided for future reference.

3.) Run the USB Driver Setup.exe file (found on the PT-Link II CD or downloaded from any of our websites) so that Prism can communicate to the PT Link II. Unzip the file to the directory where you saved your PT-Link II software.

4.) Plug the USB cable into the computer's and PT-Link II's USB ports.

5.) A message will pop-up from the lower menu bar of Windows that reads, "Found New Hardware." Click on this message and follow the instructions that appear to install the USB drivers.

6.) Open Prism II and Login with the password "Flash." If successful, "Level 4 Access" will appear at the lower right of the Prism program.

7.) Click on the **<Job-Site>** icon. The Job-Sites Window will appear. In the Type of CommLink Dialog Box, select "Hi Speed CommLink."

Type of CommLink
CommLink 2 or CommLink 3
CommLink 4 or USB Link
Hi Speed CommLink

8.) In the *Job-Sites Window*, from the Serial Port drop down list, *select* the correct COM port. If you don't know the COM port number or if the number is 10 or higher, follow the directions on pages 19-20.



9.) From Prism II's Communications tab, *select* "Flash Selected Controller."



10.) The Flash Controller Window will appear.

🖨 Flas	h Con	trollers						E
Exit Co	nnecti	on Advanced Help						
Loop:	0	Program HEX HE	X File:	c:\Documents and Setting	gs[sonya]/My Documents]	S51035_100.hex	XF	nalize HDK
Unit: 63 Program GFX GFX File: C:\PrismII\SMT5				C:\PrismII\SMTSUpdate\\	SUpdate\V200815_v100.gfx			inalize GFX
		Show Details		Check this bas for 11 B	Byte Response Packet			
Progre	alication	n (HEV) Not State			Get Info		Finalizati	on Data
	6	los J			Hardware ID:	2	Int Flash Length:	0
					Hardware Version	1	Checksum	0
Gn	sphics (	(GFX) Not Starter	d		Boot Loader ID:	-	Est Flash Length	0
-		los			Boot Loader Version:	-	Checksum	0
					Application ID:	-	and a second second	
Read	y.				Application Version:	-		

11.) From the *Flash Controller Window*'s Connection tab, *select* "Direct". Keep the *Flash Controller Window* open.

🛱 Flash Contro							
Exit	Connection						
Looj	Network						
	V Direct						

12.) Cycle power to the PT-Link II and within 5 seconds, *click* the **<Get Info>** button in the *Flash Controller Window*. The PT-Link II information will now appear in the window under the **<Get Info>** button.

Get Info	
Hardware ID:	Y\$102412
Hardware Version:	1.3
Boot Loader ID:	Y201021
Boot Loader Version:	1.0
Application ID:	\$\$1035
Application Version:	1.0

# Updating the PT-Link II Controller

13.) The Application ID should be SS1035 and the Application Version should match the software version you will be updating to.

14.) In the HEX File field, enter the path and name of the HEX file you downloaded and/or copied to your hard drive. Use the Browse button (...) to the right of the field if you need help in locating the file.

🖼 Flash Co	ontrollers	
Exit Connec	tion Advanced Help	
Loop: 0	Program HEX HEX File: c:\Documents and Settings;SS1035_100.hex	
Unit: 63	Program GFX GFX File:	

15.) Now, cycle power to the PT-Link II once again and within 5 seconds *click* on the **<Program HEX>** button (shown above). If successful, you should see the Progress Application HEX bar showing the progress percentage.

paganga
Ĵ.
Not Started

16.) When the bar shows 100% completed, verify the PT-Link II's software is running by observing the Timer LED blinking.

17.) Verify the PT-Link II's Application Version by once again cycling power to the PT-Link II and within 5 seconds *clicking* the **<Get Info>** button.

18.) Verify all fields are correct in the information below the **<Get Info>** button and under "Finalization Data." The "Int Flash Length" and "Checksum" values should match the values provided with the software sheet.

Get Info		Finaliza	ation Data
Hardware ID:	Y\$102412	Int Flash Length:	14764
Hardware Version:	1.3	Checksum:	C0DB2638
Boot Loader ID:	Y201021	Eut Elseh Lanath	FFFFFFFF
Boot Loader Version:	1.0	Charlesum	FFFFFFFF
Application ID:	SS1035	CHECKSUIII.	
Application Version:	1.0		

# Updating the PT-Link II Controller

# Finding What COM Port Number the CommLink IV is Using

1. *Left-click* on **<Start>**, located on the bottom left of the Windows Tool Bar.



2. Select <Control Panel>.



3. Double-click the System Icon.



4. *Click* the **<Hardware>** tab.



6. *Click* on the plus sign next to Ports to see all of the common ports.



- Locate the USB Serial Port (COM#). The COM# in parentheses is the port it is located on. Write this COM port number down. You will need to know this when setting up the Prism software.
- 8. If the COM port number is 10 or greater, go to "Changing the USB COM Port Number" on page 20.

5. *Click* the **<Device Manager>** button.

# Updating the PT-Link II Controller

### Changing the USB COM Port Number

When the CommLink is first plugged in, it will be assigned a COM port number to be used for communicating with the Prism software. If the port number is 10 or greater, it needs to be changed to a value less than 10 to be recognized by Prism.

- Click <Start>, click <Control Panel>, click
   <System>, click the <Hardware> tab, and then click <Device Manager> to get to the Device Manager Window.
- 2. *Click* on the plus sign next to Ports to see all of the COM ports.



Right-click on "USB Serial Port (COM#)" and select
 Properties>. In the Properties Window, select the
 Port Settings> tab.

General Port Settings Driver Details	Resources
Bits per second:	9600 🗸
Data bits:	8
Parity:	None
Stop bits:	1
Flow control:	None
Adv	vanced Restore Defaults
	OK Cancel

 To assign a port number less than 10, *click* on <Advanced>. The Advanced Settings Window will appear.

anced Settings for COM4				
OM Port Number: COM4	V			OK
USB Transfer Sizes Select lower settings to correct p Select higher settings for faster p	erformance problems at le erformance.	w baud rates.		Cancel Defaults
Receive (Bytes):	4096 💌			
Transmit (Bytes):	4096 💌			
BM Options Select lower settings to correct re	sponse problems.			
Latency Timer (msec):	16 💌			
Miscellaneous Options			_	
Minimum Read Timeout (msec):	0	Serial Enumerator Serial Printer		
Minimum Write Timeout (msec):	0 •	Event On Surprise Removal		

5. In the COM Port Number drop box, *select* which COM port you wish to use. Make sure you select a COM port number that is not currently in use (you can see the ports in use in the *Device Manager Window*). *Select* a port that is less than 10.

**NOTE:** Windows<sup>®</sup> will assign a port number to every device that has ever been installed on your computer. So if there are no available ports below 10, choose a port number less than 10 for a device listed that you know you are not currently using.

Once you select the correct COM port number, *click* <OK> and close any windows opened in the process of changing the port number. Make note of this number because you will need it for your Prism setup.

	VCM-X Modular Data Array For Field Server									
Offset	0	1	2	3	4	5	6	7		
0	AppVer	ClSt	HtSt	OaWtbl	TpDmnd	SpcTp	SaTp	RaTp		
8	ОаТр	DuctPr	OaRh	UnitMode	CtrlSts	ClEnbl	HtEnbl	EcoEnbl		
16	FanDly	PofCfg	CO2Cfg	MdHt2Ins	Rt2Ins	OnRlys	ExRlys12	ExRlys34		
24	EcoPos	VfdBwPos	VfdExPos	AlrmSts	AlrmGrp1	AlrmGrp2	AlrmGrp3	SaTpAlm		
32	OaTpAlm	SpcTpAlm	MchClAlm	MchHtAlm	PofAlm	DrtFAlm	SmokeAlm	LoSaAlm		
40	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp	InRh	InRhStM	DptStM	MdClPos		
48	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt	OcpHtSt	UnClOst	UnHtOst	WtblSt		
56	SaClSt	SaHtSt	WmupSt	SpcTpOst	SaTpOst	RaTpOst	OaTpOst	CoilTpSt		
64	DptSt	InRhSt	DuctPrSt	RfPrSt	SchdFrc	OnRly1	OnRly2	OnRly3		
72	OnRly4	OnRly5	ExRly1	ExRly2	ExRly3	ExRly4	ExRly5	ExRly6		
80	ExRly7	ExRly8	ExRly9	ExRly10	ExRly11	ExRly12	ExRly13	ExRly14		
88	ExRly15	ExRly16	CO2St	MinEcoSt	CO2Level	ByPasDmp	RaDmp	RfPr		
96	OaDwpt	CoilTp	SaTpStM	PreHtSp	OaCFM	EtCFM	SaCFM	OACfmSt		
104	OACfmRs	OACfmStM	MdCmp2	HdPr1	HdPr2	CdFan1	CdFan2	RmVFDPos		

# VCM-X Modular & VCM-X WSHP (Tulsa) Data Arrays

### Table 2: VCM-X Modular Data Array For Field Server

VCM-X WSHP (Tulsa) Data Array For Field Server									
Offset	0	1	2	3	4	5	6	7	
0	AppVer	ClSt	HtSt	OaWtbl	TpDmnd	SpcTp	SaTp	RaTp	
8	OaTp	DuctPr	OaRh	UnitMode	CtrlSts	ClEnbl	HtEnbl	EcoEnbl	
16	FanDly	PofCfg	CO2Cfg	MdHt2Ins	Rt2Ins	OnRlys	ExRlys12	ExRlys34	
24	EcoPos	VfdBwPos	VfdExPos	AlrmSts	AlrmGrp1	AlrmGrp2	AlrmGrp3	SaTpAlm	
32	OaTpAlm	SpcTpAlm	MchClAlm	MchHtAlm	PofAlm	DrtFAlm	SmokeAlm	LoSaAlm	
40	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp	InRh	InRhStM	DptStM	MdClPos	
48	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt	OcpHtSt	UnClOst	UnHtOst	WtblSt	
56	SaClSt	SaHtSt	WmupSt	SpcTpOst	SaTpOst	RaTpOst	OaTpOst	CoilTpSt	
64	DptSt	InRhSt	DuctPrSt	RfPrSt	SchdFrc	OnRly1	OnRly2	OnRly3	
72	OnRly4	OnRly5	ExRly1	ExRly2	ExRly3	ExRly4	ExRly5	ExRly6	
80	ExRly7	ExRly8	ExRly9	ExRly10	ExRly11	ExRly12	ExRly13	ExRly14	
88	ExRly15	ExRly16	CO2St	MinEcoSt	CO2Level	ByPasDmp	RaDmp	RfPr	
96	OaDwpt	CoilTp	SaTpStM	PreHtSp	OaCFM	EtCFM	SaCFM	OACfmSt	
104	OACfmRs	OACfmStM	MdCmp2	HdPr1	HdPr2	CdFan1	CdFan2	WaterTpA	
112	WaterTpB	A1LSPAlm	A1LktAlm	A2LSPAlm	A2LktAlm	B1LSPAlm	B1LktAlm	B2LSPAlm	
120	B2LktAlm	LWT1Alm	LWT2Alm	POWF1Alm	POWF2Alm	ComMAlm	RmVFDPos	_	

### Table 3: VCM-X WSHP (Tulsa) Data Array For Field Server

# VCM-X WSHP (Coil) & VCM-X Data Arrays

VCM-X WSHP (Coil) Data Array For Field Server										
Offset	0	1	2	3	4	5	6	7		
0	AppVer	ClSt	HtSt	OaWtbl	TpDmnd	SpcTp	SaTp	RaTp		
8	OaTp	DuctPr	OaRh	UnitMode	CtrlSts	ClEnbl	HtEnbl	EcoEnbl		
16	FanDly	PofCfg	CO2Cfg	MdHt2Ins	Rt2Ins	OnRlys	ExRlys12	ExRlys34		
24	EcoPos	VfdBwPos	VfdExPos	AlrmSts	AlrmGrp1	AlrmGrp2	AlrmGrp3	SaTpAlm		
32	OaTpAlm	SpcTpAlm	MchClAlm	MchHtAlm	PofAlm	DrtFAlm	SmokeAlm	LoSaAlm		
40	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp	InRh	InRhStM	DptStM	MdClPos		
48	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt	OcpHtSt	UnClOst	UnHtOst	WtblSt		
56	SaClSt	SaHtSt	WmupSt	SpcTpOst	SaTpOst	RaTpOst	OaTpOst	CoilTpSt		
64	DptSt	InRhSt	DuctPrSt	RfPrSt	SchdFrc	OnRly1	OnRly2	OnRly3		
72	OnRly4	OnRly5	ExRly1	ExRly2	ExRly3	ExRly4	ExRly5	ExRly6		
80	ExRly7	ExRly8	ExRly9	ExRly10	ExRly11	ExRly12	ExRly13	ExRly14		
88	ExRly15	ExRly16	CO2St	MinEcoSt	CO2Level	ByPasDmp	RaDmp	RfPr		
96	OaDwpt	CoilTp	SaTpStM	PreHtSp	OaCFM	EtCFM	SaCFM	OACfmSt		
104	OACfmRs	OACfmStM	MdCmp2	HdPr1	HdPr2	CdFan1	CdFan2	WaterTpA		
112	A1LSPAlm	A1LktAlm	B1LSPAlm	B1LktAlm	LWT1Alm	POWF1Alm	ComMAlm	RmVFDPos		

### Table 4: VCM-X WSHP (Coil) Data Array For Field Server

VCM-X Data Array For Field Server									
Offset	0	1	2	3	4	5	6	7	
0	AppVer	ClSt	HtSt	OaWtbl	TpDmnd	SpcTp	SaTp	RaTp	
8	OaTp	DuctPr	OaRh	UnitMode	CtrlSts	ClEnbl	HtEnbl	EcoEnbl	
16	FanDly	PofCfg	CO2Cfg	MdHt2Ins	Rt2Ins	OnRlys	ExRlys12	ExRlys34	
24	EcoPos	VfdBwPos	VfdExPos	AlrmSts	AlrmGrp1	AlrmGrp2	AlrmGrp3	SaTpAlm	
32	OaTpAlm	SpcTpAlm	MchClAlm	MchHtAlm	PofAlm	DrtFAlm	SmokeAlm	LoSaAlm	
40	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp	InRh	InRhStM	DptStM	MdClPos	
48	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt	OcpHtSt	UnClOst	UnHtOst	WtblSt	
56	SaClSt	SaHtSt	WmupSt	SpcTpOst	SaTpOst	RaTpOst	OaTpOst	CoilTpSt	
64	DptSt	InRhSt	DuctPrSt	RfPrSt	SchdFrc	OnRly1	OnRly2	OnRly3	
72	OnRly4	OnRly5	ExRly1	ExRly2	ExRly3	ExRly4	ExRly5	ExRly6	
80	ExRly7	ExRly8	ExRly9	ExRly10	ExRly11	ExRly12	ExRly13	ExRly14	
88	ExRly15	ExRly16	CO2St	MinEcoSt	CO2Level	ByPasDmp	RaDmp	RfPr	
96	OaDwpt	CoilTp	SaTpStM	PreHtSp	OaCFM	EtCFM	SaCFM	OACfmSt	
104	OACfmRs	OACfmStM	_	_	-	_	_	-	

### Table 5: VCM-X Data Array For Field Server

# SA & VCM Data Arrays

SA Controller Data Array For Field Server									
Offset	0	1	2	3	4	5	6	7	
0	AppVer	ClSt	HtSt	TpDmnd	SpcTp	SaTp	DuctPr	UnitMode	
8	CtrlSts	ClEnbl	HtEnbl	EcoEnbl	FanDly	MdHt2Ins	Rt2Ins	EcoPos	
16	VfdBwPos	SaTpAlm	SpcTpAlm	MchClAlm	MchHtAlm	PofAlm	DrtFAlm	LoSaAlm	
24	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp	InRh	InRhStM	DptStM	MdClPos	
32	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt	OcpHtSt	UnClOst	UnHtOst	SaClSt	
40	SaHtSt	WmupSt	SpcTpOst	SaTpOst	CoilTpSt	DptSt	InRhSt	DuctPrSt	
48	SchdFrc	OnRly1	OnRly2	OnRly3	OnRly4	OnRly5	ExRly1	ExRly2	
56	ExRly3	ExRly4	ExRly5	ExRly6	ExRly7	ExRly8	ExRly9	ExRly10	
64	ExRly11	ExRly12	ExRly13	ExRly14	ExRly15	ExRly16	CoilTp	SaTpStM	
72	PreHtSp	EaTp	EwTp	EaRH	HdPr1	HdPr2	CoilTp2	EaDpt	
80	WSEByp	WSEByp2	MdCmp2	CoilTpSt	CdPos1	CdPos2	EaTpAlm	EmerAlm	
88	PoWFAlm	DrnAlm	EaTpOst	EwTpOst	-	-	-	-	

### Table 6: SA Controller Data Array For Field Server

		V	CM Data A	Array For F	ield Serve	er		
Offset	0	1	2	3	4	5	6	7
0	AppVer	ClSt	HtSt	OaWtbl	TpDmnd	SpcTp	SaTp	RaTp
8	OaTp	DuctPr	OaRh	UnitMode	CtrlSts	ClDmnd	HtDmnd	DehmDmnd
16	ClEnbl	HtEnbl	EcoEnbl	FanDly	WmupDmnd	PofCfg	CO2Cfg	MdHt2Ins
24	Rt2Ins	OnRlys	ExRlys12	ExRlys34	EcoPos	VfdBwPos	VfdExPos	AlrmSts
32	AlrmGrp1	AlrmGrp2	AlrmGrp3	SaTpAlm	OaTpAlm SpcTpAlm		MchClAlm	MchHtAlm
40	PofAlm	DrtFlAlm	SmokeAlm	LoSaAlm	HiSaAlm	CtrlTpCF	CtrlTpHF	CtrlTp
48	InRh	InRhStM	DptStM	MdClPos	MdHtPos	MdHt2Pos	Rt2Pos	OcpClSt
56	OcpHtSt	UnClOst	UnHtOst	WtblSt	SaClSt	SaHtSt	WmupSt	SpcTpOst
64	SaTpOst	RaTpOst	OaTpOst	CoilTpSt	DptSt	InRhSt	DuctPrSt	RfPrSt
72	SchdFrc	OnRly1	OnRly2	OnRly3	OnRly4	OnRly5	ExRly1	ExRly2
80	ExRly3	ExRly4	ExRly5	ExRly6	ExRly7	ExRly8	ExRly9	ExRly10
88	ExRly11	ExRly12	ExRly13	ExRly14	ExRly15	ExRly16	CO2St	MinEcoSt
96	CO2Level	ByPasDmp	RaDmp	RfPr	OaDwpt	CoilTp	SaTpStM	PreHtSp

### Table 7: VCM Data Array For Field Server

# Appendix A

RJ-45 Connector as viewed from the bottom side

RJ-45 Connector as viewed from the bottom side



Use the standard EIA/TIA color code for "CROSS OVER CABLE" as shown. It is <u>not</u> the same as a standard Cat 5 patch cabling. The outer cable jacket should Be "Orange" in color. This is <u>not</u> a straight thru pin 1 to pin 1 cable.

#### Figure 25: RJ-45 8P8C Cable for WattMaster Cross Over Networking - WattMaster Part #HZ000136

### ProtoCessor Driver - (PICS) BACnet Protocol Implementation Conformance Statement

### **BACnet<sup>®</sup> Protocol**

Date: Vendor Name: Product Name:	July 13, 2006 FieldServer Technologies FieldServer
Product Model Number:	FFP-485 ProtoCessor
Product Description:	This software product will provide bi-directional communication between various RTU, DCS, SCADA and PLC using most common protocols and a BACnet system. The FieldServer can perform protocol conversion (as opposed to routing) between the different BACnet Data Link Layer options. This is arranged by way of static mappings.
Protocol Conversions:	See FieldServer Technologies list of protocol drivers available to determine available protocol conversions.

#### **BACnet Standarized Device Profile (Annex L)**

- $\sqrt{}$  BACnet Smart Sensor (B-SS)
- $\sqrt{}$  BACnet Smart Actuator (B-SA)
- $\sqrt{}$  BACnet Application Specific Controller (B-ASC)

#### BACnet Interoperability Building Blocks Supported (Annex K):

- √ K.1.1 BIBB Data Sharing ReadProperty-A (DS-RP-A)
- √ K.1.2 BIBB Data Sharing ReadProperty-B (DS-RP-B)
- √ K.1.3 BIBB Data Sharing ReadPropertyMultiple-A (DS-RPM-A)
- √ K.1.4 BIBB Data Sharing ReadPropertyMultiple-B (DS-RPM-B)
- √ K.1.7 BIBB Data Sharing WriteProperty-A (DS-WP-A)
- $\sqrt{}$  K.1.8 BIBB Data Sharing WriteProperty-B (DS-WP-B)
- √ K.1.9 BIBB Data Sharing WritePropertyMultiple-A (DS-WPM-A)
- K.1.10 BIBB Data Sharing WritePropertyMultiple-B (DS-WPM-B)
- √ K.5.1 BIBB Device Management Dynamic Device Binding-A (DM-DDB-A)

- √ K.5.2 BIBB Device Management Dynamic Device Binding-B (DM-DDB-B)
- √ K.5.4 BIBB Device Management Dynamic Object Binding-B (DM-DOB-B)

#### Segmentation Capability: None

### Standard Object Types Supported

- $\sqrt{}$  Device Object
- $\sqrt{}$  Analog Input
- √ Analog Output
- √ Analog Value
- √ Binary Input
- √ Binary Output
- $\sqrt{}$  Binary Value
- $\sqrt{}$  Multi State Input Output
- √ Multi State Output
- ✓ Multi State Value

### For all of these properties, the following applies:

- 1). Does not support BACnet CreateObject
- 2.) Does not support BACnet DeleteObject
- 3.) Does not support any optional properties
- 4.) No additional writeable properties exist
- 5.) No proprietary properties exist
- 6.) No range restrictions exist

#### Data Link Layer Options:

- $\sqrt{}$  MS/TP master (Clause 9), baud rate up to 76800 bps
- $\sqrt{MS/TP}$  slave (Clause 9), baud rate up to 76800 bps

#### Device Address Binding: Not supported

#### **Character Sets Supported:**

Where support for multiple character sets is indicated, this does not imply that they can all be supported simultaneously.

√ ANSI X3.4

# Appendix C - VCM-X Modular and WSHP BACnet Parameters

**NOTE:** The following points for the VCM-X Modular and VCM-X WSHP Controllers are additional points. All points and property identifiers in the VCM-X Controller table (pages 28-33) also apply to the VCM-X Modular and VCM-X WSHP Controllers.

BACn	et Proper	ties for	VCM-X Modu	lar	
Parameter	Name	Object	Description	Lin	nits
Modulating Compressor 2	MdCmp2	AI: 206	Current position of the 2nd Stage of Compressor Modulation.		
Head Pressure 1	HdPr1	AI: 207	Head Pressure for 1st Compressor		
Head Pressure 2	HdPr2	AI: 208	Head Pressure for 2nd Compressor		
Condenser Fan 1	CdFan1	AI: 209	Condenser Fan 1 Signal Status		
Condenser Fan 2	CdFan2	AI: 210	Condenser Fan 2 Signal Status		
Remote VFD Reset	RmVFDPos	AO: 258	Remote VFD Position Reset	-1	100

BACnet F	Properties	s for VC	M-X WSHP	(Tuls	a)
Parameter	Name	Object	Description	Lim	nits
Modulating Compressor 2	MdCmp2	AI: 206	Current position of the 2nd Stage of Compressor Modulation.		
Head Pres- sure 1	HdPr1	AI: 207	Head Pressure for 1st Compressor		
Head Pres- sure 2	HdPr2	AI: 208	Head Pressure for 2nd Compressor		
Condenser Fan 1	CdFan1	AI: 209	Condenser Fan 1 Signal Status		
Condenser Fan 2	CdFan2	AI: 210	Condenser Fan 2 Signal Status		
Water Temp. A	WaterTpA	AI: 220	Current water temperature of refrigerant for System A.		
Water Temp. B	WaterTpB	AI: 221	Current water temperature of refrigerant for System B.		
Remote VFD Reset	RmVFDPos	AO: 258	Remote VFD Position Reset	-1	100

BACnet F	Properties	s for VC	M-X WSHP	(Tuls	a)
Parameter	Name	Object	Description	Lim	its
Compressor A1 Low Suction Pressure Alarm	A1LSPAlm	BI: 222	Alarm that indicates Suction Pressure for Compressor A1 is below the Low Suction Pressure Cooling (Heat- ing) Setpoint.		
Compressor A1 Lockout Alarm	A1LktAlm	BI: 223	Alarm that indicates Compressor A1 is locked out.		
Compressor A2 Low Suction Pressure Alarm	A2LSPA1m	BI: 224	Alarm that indicates Suction Pressure for Compressor A2 is below the Low Suction Pressure Cooling (Heat- ing) Setpoint.		
Compressor A2 Lockout Alarm	A2LktAlm	BI: 225	Alarm that indicates Compressor A2 is locked out.		
Compressor B1 Low Suction Pressure Alarm	B1LSPAlm	BI: 226	Alarm that indicates Suction Pressure for Compressor B1 is below the Low Suction Pressure Cooling (Heat- ing) Setpoint.		
Compressor B1 Lockout Alarm	B1LktAlm	BI: 227	Alarm that indicates Compressor B1 is locked out.		
Compressor B2 Low Suction Pressure Alarm	B2LSPAlm	BI: 228	Alarm that indicates Suction Pressure for Compressor B2 is below the Low Suction Pressure Cooling (Heat- ing) Setpoint.		
Compressor 4 Lockout Alarm	B2LktAlm	BI: 229	Alarm that indicates Compressor B2 is locked out.		
Low Water Temperature 1 Alarm	LWT1Alm	BI: 230	Alarm that indicates water temperature is below the Leaving Water Safety Setpoint (Heating only) for System A.		

# Appendix C - VCM-X Modular and WSHP BACnet Parameters

<b>BACnet</b>	Properties	s for V(	CM-X WSHP	(Tulsa)	
Parameter	Name	Object	Description	Limits	
Low Water Temperature 2 Alarm	LWT2Alm	BI: 231	Alarm that indicates water temperature is below the Leaving Water Safety Setpoint (Heating only) for System B		
Proof of Water 1 Flow Alarm	POWF1Alm	BI: 232	Alarm that indicates no Proof of Water Flow for System A (A1/A2)		
Proof of Water 2 Flow Alarm	POWF2Alm	BI: 233	Alarm that indicates no Proof of Water Flow for System B (B1/B2)		
Module Communica- tions Alarm	ComMAlm	BI: 234	Alarm that indicates that one or more Modules are not communicating with the VCM-X WSHP Control- ler.		

BACnet	Propertie	s for V	CM-X WSH	P (Co	oil)
Parameter	Name	Object	Description	Lin	nits
Modulating Compressor 2	MdCmp2	AI: 206	Current posi- tion of the 2nd Stage of Compressor Modulation.		
Head Pressure 1	HdPr1	AI: 207	Head Pressure for 1st Compressor		
Head Pressure 2	HdPr2	AI: 208	Head Pressure for 2nd Compressor		
Condenser Fan 1	CdFan1	AI: 209	Condenser Fan 1 Signal Status		
Condenser Fan 2	CdFan2	AI: 210	Condenser Fan 2 Signal Status		
Water Temp. A	WaterTpA	AI: 220	Current water temperature.		
Remote VFD Reset	RmVFDPos	AO: 258	Remote VFD Position Reset	-1	100

BACnet	Propertie	s for V	CM-X WSH	Р (Со	il)
Parameter	Name	Object	Description	Lin	nits
Compressor A Low Suction Pressure Alarm	A1LSPAlm	BI: 222	Alarm that indicates Suction Pressure for Circuit A is below the Low Suction Pressure Cool- ing (Heating) Setpoint.		
Compressor A Lockout Alarm	A1LktAlm	BI: 223	Alarm that indicates Circuit A Compressors are locked out.		
Compressor B Low Suction Pressure Alarm	B1LSPAlm	BI: 226	Alarm that indicates Suction Pressure for Circuit B is below the Low Suction Pressure Cool- ing (Heating) Setpoint.		
Compressor B Lockout Alarm	B1LktAlm	BI: 227	Alarm that indicates Circuit B Compressors are locked out.		
Low Water Temperature Alarm	LWT1Alm	BI: 230	Alarm that in- dicates water temperature is below the Leaving Water Safety Setpoint (Heating only).	in- ter re he ater t	
Proof of Water Flow Alarm	POWF1Alm	BI: 232	Alarm that indicates no Proof of Water Flow.		
Module Communica- tions Alarm	ComMAIm	BI: 234	Alarm that indicates that one or more Modules are not commu- nicating with the VCM-X WSHP Controller.		

# PT-Link II BACnet<sup>®</sup> Technical Guide

BACr	net Prop	erties f	for the VCM-X (	Controller	ler BACnet Properties for the VCM-X Control				
Parameter	Name	Object	Description	Limits	Parameter	Name	Object	Description	Limits
Alarm Status	AlrmSts	AI: 1	Needed only in legacy application.		Space Temperature	SpcTp	AI: 72	Current value of the space temperature sensor	
Control Status	CtrlSts	AI: 4	Current operational status.		Current	SaTpStM	AI: 82	Current SAT	
Occupied/ Mode Enable Cooling Setpoint Mirror	ClSt	AI: 7	Occupied/ Mode Enable Cooling Setpoint Mirror.		Supply Air Setpoint			Cooling or Heating setpoint if there is no reset source; Current calculated SAT setpoint with Reset Source.	
Control Temperature	CtrlTp	AI: 9	Current value of the control temperature sensor.		Supply Air Temperature	SaTp	AI: 83	Current value of the supply air temperature sensor.	
Duct Static Pressure	DuctPr	AI: 14	Current value of the duct static pressure sensor.		Temperature Demand	TpDmnd	AI: 84	Based on the comparison between the	
Economizer Position	EcoPos	AI: 16	Current position of the economizer damper.					Temperature and the Heating or Cooling Setpoint	
Occupied/ Mode Enable	HtSt	AI: 31	Occupied/ Mode Enable Heating Setpoint					Temperatures. Does not work for supply air control	
Heating Setpoint Mirror			Mirror.		VFD Blower Fan	VfdBw- Pos	AI: 88	Current position of the VFD blower fan signal.	
Modulating Gas Valve Position	MdHt- 2Pos	AI: 38	Current position of MODGAS II modulating gas valve control		VFD Relief Fan	VfdExPos	AI: 89	Current position of the VFD relief fan signal.	
On Board Relays	OnRlys	AI: 44	Needed only in legacy application.		Application Software Version	AppVer	AI: 99	Current version of the software in the unit.	
Outdoor Air Dewpoint	OaDwpt	AI: 47	Current calculated outdoor air dewpoint added on		Alarm Group 1	AlrmGrp1	AI: 104	Needed only in legacy application.	
Outdoor Air	OaPh	AT: 52	version 1.09.		Alarm Group 2	AlrmGrp2	AI: 105	Needed only in legacy application.	
Humidity	Ourdi	111. 52	outdoor humidity sensor.		Alarm Group 3	AlrmGrp3	AI: 106	Needed only in legacy application.	
Outdoor Air Temperature	OaTp	AI: 54	Current value of the outdoor tempera- ture sensor.		Dewpoint Setpoint Mirror	DptStM	AI: 110	Mirror of the DPtSt "read only."	
Outdoor Air Wetbulb	OaWtbl	AI: 55	Current calculated value of the out-		External Relays 1-2	ExRlys12	AI: 111	Needed only in legacy application.	
			door wetbulb temperature.		External Relays 3-4	ExRlys34	AI: 112	Needed only in legacy application.	
Reheat Value Position	Rt2Pos	AI: 60	Current position of MHGRV modulat- ing hot gas reheat		Indoor Rh Setpoint Mirror	InRhStM	AI: 114	Mirror of the InRhSt "read only."	
Relief Pressure	RfPr	AI: 62	Current value of the building pressure sensor.		Modulating Cool Position	MdClPos	AI: 115	Current position of the modulating cooling signal (Chilled water or digital compressor)	
Return Air Temperature	КаТр	AI: 64	Current value of the return temperature sensor.		Modulating Heat	MdHtPos	AI: 116	Current position of the modulating	
Indoor Humidity	InRh	AI: 67	Current value of the indoor humidity sensor.		Position			neating signal (hot water or SCR heat).	

BACr	net Prop	erties f	or the VCM-X	Conti	ontroller BACnet Properties for the VCM-X Controller						
Parameter	Name	Object	Description	Lin	nits	Parameter	Name	Object	Description	Lin	nits
Unit Mode	UnitMode	AI: 123	Needed only in legacy application.			Outdoor Air Sensor	OaTpOst	AO: 53	If the Outdoor Temperature Sensor	-100	100
Return Air CO <sub>2</sub> Level	CO2Level	AI: 150	Current value of the $CO_2$ sensor.			Oliset			incorrectly, you can use this option to		
Bypass Damper Position	ByPas- Dmp	AI: 153	Current position of the bypass damper signal.						enter an offset temperature to adjust the Sensor's		
Return Damper Position	RaDmp	AI: 154	Current position of the return damper signal.			Return Air Sensor	RaTpOst	AO: 65	If the Return Tem- perature Sensor is	-100	100
Coil Temperature	CoilTp	AI: 181	Current coil temperature reading added on version 1.09.			Offset			reading incorrectly, you can use this option to enter an offset temperature to adjust the Sen-		
Outdoor Air CFM	OaCFM	AI: 193	Current Outdoor Airflow Measurement			Schedule	SchdFrc	AO: 66	sor's Temperature. 0 = Auto/	0	2
Exhaust CFM	EtCFM	AI: 194	Current Exhaust Airflow Measurement			Force			Unoccupied Mode 1 = Forced On 2 = Forced Off		
Supply Air CFM	SaCFM	AI: 195	Current Supply Airflow Measurement			Space Sensor Offset	SpcTpOst	AO: 71	If the Space Temperature Sensor is reading incorrectly, you can	-100	100
Current Calculated OA CFM setpoint	OACfm- StM	AI: 205	Current calculated Outdoor Air CFM based on CO <sub>2</sub> level.	25					use this option to enter an offset temperature to adjust the Sensor's Temperature.		
Setpoint	DptSt	AU: 13	above this setpoint, the unit will	35	80	SAT Cooling Setpoint	SaClSt	AO: 77	Supply Air Setpoint in Cooling Mode.	40	80
			activate the Dehumidification Demand.			SAT Heating Setpoint	SaHtSt	AO: 78	Supply Air Setpoint in Heating Mode.	40	200
Occupied/ Mode Enable Cooling Setpoint	OcpClSt	AO: 42	If the control tem- perature rises one degree above this setpoint, the control will activate the cooling demand. If the control temperature is the Supply Air Sensor, then the cooling	0	99	Supply Air Sensor Offset	SaTpOst	AO: 80	If the Supply Air Temperature Sensor is reading incor- rectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature.	-100	100
			demand is always active.			Warm Up Setpoint	WmupSt	AO: 91	In a VAV application, upon entering the	50	90
Occupied/ Mode Enable Heating Setpoint	OcpHtSt	AO: 43	If the control temperature drops one degree below this setpoint, the control will activate the heating demand. If the control		99				occupied mode, the Warm-up Demand will be activated if the return air temperature falls one degree below this setpoint.		
			temperature is the Supply Air Sensor, then there is no heating demand.								

# PT-Link II BACnet<sup>®</sup> Technical Guide

BACr	net Prop	erties f	or the VCM-X	Cont	roller	BACr	net Prop	erties f	for the VCM-X	Cont	roller
Parameter	Name	Object	Description	Lir	nits	Parameter	Name	Object	Description	Lir	nits
Wet Bulb Setpoint	WtblSt	AO: 92	The economizer is enabled if the outdoor tem- perature or wetbulb falls below this setpoint.	0	80	CO <sub>2</sub> Setpoint	CO2St	AO: 149	When the CO <sub>2</sub> level rises above the CO <sub>2</sub> Protection Limit Max Level, the Economizer's Minimum Position	0	3000
Coil Temperature Setpoint	CoilTpSt	AO: 107	This is the coil suction temperature target during dehumidification mode. Produces dewpoint in the supply air	35	70				will begin to reset open proportionally between the CO <sub>2</sub> Protection Limit Max Level Setpoint and the Reset Range Setpoint.		
Relief Pressure Setpoint	RfPrSt	AO: 118	approximately 10°F above this setpoint. This is the target building pressure to be maintained	-0.2	0.2	Minimum Outside Air Setpoint	MinEcoSt	AO: 151	This is the minimum position of the economizer in the occupied modes.	1	100
Indoor	InRhSt	AO: 120	by the VFD Relief signal.	0	100	Static Pressure Setpoint	DuctPrSt	AO: 152	This is the target duct pressure to be maintained by the VFD blower signal.	0.01	3
Setpoint			above this setpoint, the unit will activate the			Preheater Setpoint	PreHtSp	AO: 196	Low Outside Air Ambient Protection Setpoint	0	100
Unoccupied	UnClOst	AO: 124	Denumidification Demand. During the	0	30	Outdoor Air CFM Setpoint	OACfmSt	AO: 203	Minimum desired Outdoor Air CFM.	0.10 K	200 K
Cooling Offset			Unoccupied Mode of Operation, this Setpoint spreads the Occupied Cool- ing Setpoint out by a user adjustable amount. If you do not want Cooling to			Outdoor Air CFM Reset Limit	OACfmRs	AO: 204	Maximum desired Outdoor Air CFM when CO <sub>2</sub> reaches its reset limit.	0.10 K	200 K
			operate during the Unoccupied Mode, use the default setting of 30°F for these setpoints.								
Unoccupied Heating Offset	UnHtOst	AO: 125	During the Unoccupied Mode of Operation, this Setpoint spreads the Occupied Heating Setpoint out by a user adjustable amount. If you do not want Heating to operate during the Unoc- cupied Mode, use the default setting of 30°F for these setpoints.	0	30						

BACnet	Properti	es for t	he VCM-X Cor	troller	BACnet	Properti	es for t	he VCM-X Cor	ntroller
Parameter	Name	Object	Description	Limits	Parameter	Name	Object	Description	Limits
Bad Supply Air Sensor	SaTpAlm	BI: 2	Alarm that indicates a failure in the supply air sensor.		Mechanical Cooling Alarm	MchClAlm	BI: 94	Compressor Relays are enabled but the Supply Air Temperature has	
CO <sub>2</sub> Sensor Installed	CO2Cfg	BI: 3	Status that indicates the $CO_2$ function has been configured.					not fallen 5°F w/m a user-adjustable time period. This does not indicate compressors are	
Cooling Enabled	ClEnbl	BI: 6	Status that indicates mechanical cooling is enabled.		Mechanical	MchHtAlm	BI: 05	active and will not shut the unit down.	
Economizer Enabled	EcoEnbl	BI: 15	Status that indicates the economizer is enabled.		Heating Alarm	MenintAnn	DI. 95	been initiated but the Supply Air Temperature has	
Fan Start Up Delay	FanDly	BI: 25	Status that indicates the fan is commanded to run, but it is in the start up delay mode.					not risen 5°F w/in a user-adjustable time period. This does not indicate heat stages are active and will not	
Fan Proving Alarm	PofAlm	BI: 26	Alarm that indicates a failure in the flow of the VFD blower		Dirty Filter Detected	DrtFlAlm	BI: 96	shut the unit down. Alarm that indicates the filters are dirty.	
Heating Enabled	HtEnbl	BI: 30	Status that indicates that mechanical heating is enabled.		Control Temperature Cool Failure	CtrlTpCF	BI: 108	This alarm is activated if the control temperature does not get within	
High Supply Air Temperature Alarm	HiSaAlm	BI: 33	The Supply Air has risen above the Hi SAT Cutoff Setpoint. Heating stages begin to deac- tivate and the fan continues to run.					s F to the occupied cooling setpoint in an hour in the cooling mode. This alarm is not used in 100% outside air units or supply air control.	
Low Supply Air Temperature Alarm	LoSaAlm	BI: 37	The Supply Air has fallen below the Hi SAT Cutoff Setpoint and cooling stages will begin to deacti- vate. If the unit is in Economizer, Vent, or Heating Mode the Supply Fan will shut off.		Control Temperature Heat Failure	CtrlTpHF	BI: 109	This alarm is activated if the control temperature does not get within 5°F to the occupied heating setpoint in an hour in the heating mode. This alarm is not used in 100% outside air	
MODGAS II Connected	MdHt2Ins	BI: 39	Status that indicates the MODGAS II controller is		Outdoor Air	OaTpAlm	BI: 117	units or supply air control. Alarm that	
Proof of Flow	PofCfg	BI: 57	connected. Status that indicates the proof of flow function has been		Temperature Lost			indicates a failure in the outdoor air temperature.	
REHEAT II	Rt2Ins	BI: 58	configured. Status that indicates		Smoke Detected Alarm	SmokeAlm	BI: 119	Alarm that indicates the Smoke sensor has been activated.	
Connected			the MHGRV controllers is connected to the system.		Space Temperature Sensor Lost	SpcTpAlm	BI: 101	Alarm that indicates a failure in the space temperature sensor.	

BACnet Properties for the VCM-X Controller									
Parameter	Name	Object	Description	Limits					
On Board Relay 1	OnRly1	BI: 127	Current status of relay 1.						
On Board Relay 2	OnRly2	BI: 128	Current status of relay 2.						
On Board Relay 3	OnRly3	BI: 129	Current status of relay 3.						
On Board Relay 4	OnRly4	BI: 130	Current status of relay 4.						
On Board Relay 5	OnRly5	BI: 131	Current status of relay 5.						
Expansion Relay 1	ExRly1	BI: 133	Current status of relay 6.						
Expansion Relay 2	ExRly2	BI: 134	Current status of relay 7.						
Expansion Relay 3	ExRly3	BI: 135	Current status of relay 8.						
Expansion Relay 4	ExRly4	BI: 136	Current status of relay 9.						
Expansion Relay 5	ExRly5	BI: 137	Current status of relay 10.						
Expansion Relay 6	ExRly6	BI: 138	Current status of relay 11.						
Expansion Relay 7	ExRly7	BI: 139	Current status of relay 12.						
Expansion Relay 8	ExRly8	BI: 140	Current status of relay 13.						
Expansion Relay 9	ExRly9	BI: 141	Current status of relay 14.						
Expansion Relay 10	ExRly10	BI: 142	Current status of relay 15.						
Expansion Relay 11	ExRly11	BI: 143	Current status of relay 16.						
Expansion Relay 12	ExRly12	BI: 144	Current status of relay 17.						
Expansion Relay 13	ExRly13	BI: 145	Current status of relay 18.						
Expansion Relay 14	ExRly14	BI: 146	Current status of relay 19.						
Expansion Relay 15	ExRly15	BI: 147	Current status of relay 20.						
Expansion Relay 16	ExRly16	BI: 148	Current status of relay 21.						

## **VCM-X PT-Link-BACnet®** Property Identifier:

The PT-Link-BACnet® Link amends the following property identity to the BACnet® property identifier.

### **BACNETPropertyIdentifier :**

WattBACNETScheduleForce :	:= ENUMERATED {
---------------------------	-----------------

NormalOperation	(0),
ForceOccupied	(1),
ForceUnoccupied	(2)
}	

VcmxUnitMode ::= ENUMERATED {	
Unoccupied	(0),
RemoteContactOccupied	(1),
NormalScheduleOccupied	(2),
PushButtonOrZoneOverride	(3),
HolidayModeActive	(4),
UnoccupiedZoneDemand	(5),
RemoteScheduleOverride	(6),
CurrentOutputForceMode	(7),
SATHighOrLowCutOff	(8),
CO2OverrideInProgress	(9),
PurgeModeActive	(10)
}	

#### VcmxControlStatusBits ::= ENUMERATED {

Off	(0),
Vent	(1),
Cool	(2),
Heat	(3),
Dehum	(4),
Dehum Cool	(5),
Dehum Heat	(6),
Warm Up Mode	(7)
}	

#### VcmxOnBoardRelaysBits ::= BIT STRING { (0)OnBoardRelav1

Onbourarconayr	(0),
OnBoardRelay2	(1),
OnBoardRelay3	(2),
OnBoardRelay4	(3),
OnBoardRelay5	(4)
}	

VcmxExternal Relays1-2Bits::= BIT STRING {							
ExpansionBoard1Relay1	(0),						
ExpansionBoard1Relay2	(1),						
ExpansionBoard1Relay3	(2),						
ExpansionBoard1Relay4	(3),						
ExpansionBoard2Relay1	(4),						
ExpansionBoard2Relay2	(5),						
ExpansionBoard2Relay3	(6),						
ExpansionBoard2Relay4	(7)						
}							
VcmxExternal Relays2-4Bits::= BIT STRIN	VcmxExternal Relays2-4Bits::= BIT STRING {						
ExpansionBoard3Relay1	(0),						
ExpansionBoard3Relay2	(1),						
ExpansionBoard3Relay3	(2),						
ExpansionBoard3Relay4	(3),						
ExpansionBoard4Relay1	(4),						
ExpansionBoard4Relay2	(5),						
ExpansionBoard4Relay3	(6),						
ExpansionBoard4Relay4	(7)						
}							
VcmxAlarmStatusBits ::= BIT STRING {							
Alarm Group1	(0),						
Alarm Group?	(1)						

Alarm Group2	(1),
Alarm Group3	(2)
}	

VcmxAlarmGroup1Bits ::= BIT STRING {	
SupplyTempSensorFailure	(0),
LostOutdoorTempSensorSignal	(1),
LostSpaceTempSensorSignal	(2)
}	
VcmxAlarmGroup2Bits ::= BIT STRING {	
MechanicalCoolingAlarm	(0),
MechanicalHeatingAlarm	(1),
FanProvingAlarm	(2),
DirtyFilterDetected	(3),
SmokeDetected	(4)
}	
VcmxAlarmGroup3Bits ::= BIT STRING {	
LowSupplyAirTempAlarm	(0),
HighSupplyAirTempAlarm	(1),
LowControlTempAlarm	(2),
HighControlTempAlarm	(3)
}	

# PT-Link II BACnet<sup>®</sup> Technical Guide

# Appendix E - SA Controller BACnet Parameters

BA	s for SA Contro	oller	BACnet Properties for SA Controller						
Parameter	Name	Object	Description	Limits	Parameter	Name	Object	Description	Limits
Control Status	CtrlSts	AI: 4	Current operational status.		Application Software Version	AppVer	AI: 99	Current version of the software in the unit.	
Mode Enable Cooling	CISt	AI: 7	Enable Cooling Setpoint Mirror.		Coil Temperature Setpoint	CoilTpSt	AI: 107	Current Coil Temperature Setpoint.	
Mirror	CtrlTn	AI- 9	Current value of the		Dewpoint Setpoint Mirror	DptStM	AI: 110	Mirror of the DPtSt "read only."	
Temperature	Currp	AI. 9	control temperature sensor.		Indoor RH Setpoint	InRhStM	AI: 114	Mirror of the InRhSt "read only."	
Duct Static Pressure	DuctPr	AI: 14	Current value of the duct static pressure sensor.		Mirror Modulating	MdClPos	AI: 115	Current position of	
Economizer Position	EcoPos	AI: 16	Current position of the economizer damper.		Position			cooling signal (Chilled water or digital compressor).	
Occupied/ Mode Enable Heating	HtSt	AI: 31	Occupied/ Mode Enable Heating Setpoint Mirror.		Modulating Heat Position	MdHtPos	AI: 116	Current position of the modulating heating signal (hot water or SCR heat).	
Setpoint Mirror					Unit Mode	UnitMode	AI: 123	Needed only in legacy application.	
Modulating Gas Valve Position	MdHt- 2Pos	AI: 38	Current position of MODGAS II modulating gas valve control.		Coil Temperature	CoilTp	AI: 181	Current coil temperature reading added on version 1.09.	
Reheat Value Position	Rt2Pos	AI: 60	Current position of MHGRV modulating hot gas reheat valve control.		Modulating Compressor 2 Position	MdCmp2	AI: 206	Current position of the 2nd Stage of Compressor Modulation.	
Indoor Humidity	InRh	AI: 67	Current value of the indoor humidity sensor.		Head Pressure 1	HdPr1	AI: 207	Head Pressure for 1st unit.	
Space Temperature	SpcTp	AI: 72	Current value of the space temperature		Head Pressure 2	HdPr2	AI: 208	Head Pressure for 2nd unit.	
Current	SaTpStM	AI: 82	sensor. Current SAT		Entering Air Temperature	EaTp	AI: 235	air that is entering the unit.	
Setpoint			setpoint if there is no reset source; Current calculated		Entering Water Temperature	EwTp	AI: 236	Temperature of the water that is entering the unit.	
			SAT setpoint with Reset Source.		Entering Air Humidity	EaRh	AI: 237	Relative Humidity of the Entering Air.	
Supply Air Temperature	SaTp	AI: 83	Current value of the supply air temperature sensor.		Coil Temperature 2	CoilTp2	AI: 240	Current Coil Temperature for 2nd unit.	
Temperature Demand	TpDmnd	AI: 84	Based on the comparison between		Entering Air Dewpoint	EaDpt	AI: 241	Current Entering Air Dewpoint	
			Temperature and the Heating or Cooling Setpoint Tempera-		Water Side Economizer Bypass	WSEByp	AI: 242	Current Water Side Economizer Bypass Position for 1st unit.	
VED	VfdBw	AT- 88	tures. Does not work for supply air control		Water Side Economizer Bypass 2	WSEByp2	AI: 243	Current Water Side Economizer Bypass Position for 2nd unit.	
Blower Fan	Pos	711. 00	the VFD blower fan signal.		Condenser Position 1	CdPos1	AI: 246	Current Condenser Position for 1st unit.	

# Appendix E - SA Controller BACnet Parameters

BACnet Properties for SA Controller					BAC	net Prop	erties	for SA Contro	ller		
Parameter	Name	Object	Description	Limits		Parameter	Name	Object	Description	Lin	nits
Condenser Position 2	CdPos2	AI: 247	Current Condenser Position for 2nd unit.			Supply Air Sensor Offset	SaTpOst	AO: 80	If the Supply Air Temperature Sensor	-100	100
Dewpoint Setpoint	DptSt	AO: 13	If the outdoor dewpoint rises above this setpoint, the unit will activate the Dehumidification Demand.	35	80				incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature.		
Occupied/ Mode Enable Cooling Setpoint	OcpCISt	AO: 42	If the control temperature rises one degree above this setpoint, the control will activate the cool- ing demand. If the control temperature is the Supply Air Sen- sor, then the cooling demand is always active.	0	99	Warm Up Setpoint	WmupSt	AO: 91	In a VAV application, upon entering the occupied mode, the Warm-up Demand will be activated if the return air temperature falls one degree below this setpoint.	50	90
Occupied/ Mode Enable Heating Setpoint	OcpHtSt	AO: 43	If the control temperature drops one degree below this setpoint, the control will activate the heating demand. If the control temperature is the Supply Air		99	Coil Temperature Setpoint	CoilTpSt	AO: 107	This is the coil suction temperature target during dehumidification mode. Produces dewpoint in the supply air approximately 10°F above this setpoint.	35	70
			Sensor, then there is no heating demand.			Indoor Humidity Setpoint	InRhSt	AO: 120	If the indoor humidity rises above this setpoint.	0	100
Force	SendFre	AU: 00	Unoccupied Mode 1 = Forced On 2 = Forced Off	0	2				the unit will activate the Dehumidification Demand.		
Space Sensor Offset	SpcTpOst	AO: 71	If the Space Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature.	-100	100	Unoccupied Cooling Offset	UnClOst	AO: 124	During the Unoccupied Mode of Operation, this Setpoint spreads the Occupied Cool- ing Setpoint out by a user adjustable amount. If you do not want Cooling to	0	30
SAT Cooling Setpoint	SaClSt	AO: 77	Supply Air Setpoint in Cooling Mode.	40	80				operate during the Unoccupied Mode, use the default		
SAT Heating Setpoint	SaHtSt	AO: 78	Supply Air Setpoint in Heating Mode.	40	200				setting of 30°F for these setpoints.		

# PT-Link II BACnet<sup>®</sup> Technical Guide

# Appendix E - SA Controller BACnet Parameters

BAC	net Prop	perties	for SA Contro	ller		BAC	BACnet Properties for SA Controller			
Parameter	Name	Object	Description	Lir	nits	Parameter	Name	Object	Description	
Unoccupied Heating	UnHtOst	AO: 125	During the Unoccupied Mode	0	30	Bad Supply Air Sensor	SaTpAlm	BI: 2	Alarm that indicates a failure in the supply air sensor.	
Offset			of Operation, this Setpoint spreads the Occupied			Cooling Enabled	ClEnbl	BI: 6	Status that indicates mechanical cooling is enabled.	
			Heating Setpoint out by a user			Economizer Enabled	EcoEnbl	BI: 15	Status that indicates the economizer is enabled.	
			If you do not want Heating to operate during the Unoc-			Fan Start Up Delay	FanDly	BI: 25	Status that indicates the fan is commanded to run, but it is in the start up delay mode.	
			cupied Mode, use the default setting of 30°F for these			Fan Proving Alarm	PofAlm	BI: 26	Alarm that indicates a failure in the flow of the VFD blower.	
Static	DuctPrSt	AO: 152	setpoints. This is the target	0.01	3	Heating Enabled	HtEnbl	BI: 30	Status that indicates that me- chanical heating is enabled.	
Pressure Setpoint			duct pressure to be maintained by the VFD blower signal.			High Supply Air Temperature	HiSaAlm	BI: 33	The Supply Air has risen above the Hi SAT Cutoff Setpoint. Heating stages begin to	
Preheater Setpoint	PreHtSp	AO: 196	Low Outside Air Ambient	0	100	Alarm			deactivate and the fan continues to run.	
Entering Air Offset Setpoint	EaTpOst	AO: 238	Protection Setpoint If the Entering Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset			Low Supply Air Temperature Alarm	LoSaAlm	BI: 37	The Supply Air has fallen below the Hi SAT Cutoff Setpoint and cooling stages will begin to deactivate. If the unit is in Economizer, Vent, or Heating Mode the Supply Fan will shut off.	
			temperature to adjust the Sensor's Temperature.			MODGAS II Connected	MdHt2Ins	BI: 39	Status that indicates the MODGAS II controller is connected.	
Entering Water Offset Setpoint	EwTpOst	AO: 239	If the Entering Water Temperature Sensor is reading incorrectly, you can use this option			REHEAT II Connected	Rt2Ins	BI: 58	Status that indicates the MHGRV controllers is connected to the system.	
			to enter an offset temperature to adjust the Sensor's Temperature.			Mechanical Cooling Alarm	MchClAlm	BI: 94	Compressor Relays are enabled but the Supply Air Temperature has not fallen 5°F w/in a user- adjustable time period. This does not indicate compressors are active and will not schut the unit down	

# Appendix E - SA Controller BACnet Parameters

BAC	net Prope	BACnet Properties for SA Controller						
Parameter	Name	Object	Description					
Mechanical Heating Alarm	MchHtAlm	BI: 95	Heating Mode has been initiated but the Supply Air Temperature has not risen 5°F w/in a user-adjustable time period. This does not indicate heat stages are active and will not shut the unit down.					
Dirty Filter Detected	DrtFlAlm	BI: 96	Alarm that indicates the filters are dirty.					
Control Temperature Cool Failure	CtrlTpCF	BI: 108	This alarm is activated if the control temperature does not get within 5°F to the occupied cooling setpoint in an hour in the cooling mode. This alarm is not used in 100% outside air units or supply air control.					
Control Temperature Heat Failure	CtrlTpHF	BI: 109	This alarm is activated if the control temperature does not get within 5°F to the occupied heating setpoint in an hour in the heating mode. This alarm is not used in 100% outside air units or supply air control.					
Space Temperature Sensor Lost	SpcTpAlm	BI: 101	Alarm that indicates a failure in the space temperature sensor.					
On Board Relay 1	OnRly1	BI: 127	Current status of relay 1.					
On Board Relay 2	OnRly2	BI: 128	Current status of relay 2.					
On Board Relay 3	OnRly3	BI: 129	Current status of relay 3.					
On Board Relay 4	OnRly4	BI: 130	Current status of relay 4.					
On Board Relay 5	OnRly5	BI: 131	Current status of relay 5.					
Expansion Relay 1	ExRly1	BI: 133	Current status of relay 6.					
Expansion Relay 2	ExRly2	BI: 134	Current status of relay 7.					
Expansion Relay 3	ExRly3	BI: 135	Current status of relay 8.					
Expansion Relay 4	ExRly4	BI: 136	Current status of relay 9.					
Expansion Relay 5	ExRly5	BI: 137	Current status of relay 10.					
Expansion Relay 6	ExRly6	BI: 138	Current status of relay 11.					
Expansion Relay 7	ExRly7	BI: 139	Current status of relay 12.					
Expansion Relay 8	ExRly8	BI: 140	Current status of relay 13.					
Expansion Relay 9	ExRly9	BI: 141	Current status of relay 14.					
Expansion Relay 10	ExRly10	BI: 142	Current status of relay 15.					

BACnet Properties for SA Controller					
Parameter	Name	Object	Description		
Expansion Relay 11	ExRly11	BI: 143	Current status of relay 16.		
Expansion Relay 12	ExRly12	BI: 144	Current status of relay 17.		
Expansion Relay 13	ExRly13	BI: 145	Current status of relay 18.		
Expansion Relay 14	ExRly14	BI: 146	Current status of relay 19.		
Expansion Relay 15	ExRly15	BI: 147	Current status of relay 20.		
Expansion Relay 16	ExRly16	BI: 148	Current status of relay 21.		
Emergency Shutdown Alarm	EmerAlm	BI: 219	Alarm that indicates Emergency Shutdown.		
Drain Pan Overflow	DrnAlm	BI: 244	Alarm that indicates overflow of the drain pan.		
Proof of Water Flow Alarm	PoWFAlm	BI: 245	Alarm that indicates no Proof of Water Flow.		
Entering Air Temperature Alarm	EaTpAlm	BI: 248	Alarm that indicates failure in the Entering Air Temperature Sensor.		

## SA Controller PT-Link-BACnet® Property Identifier:

The PT-Link-BACnet<sup>®</sup> Link amends the following property identity to the BACnet<sup>®</sup> property identifier.

### **BACNETPropertyIdentifier :**

VcmxControlStatusBits ::= ENUMERATED {

	(
Off	(0),
Vent	(1),
Cool	(2),
Heat	(3),
Dehum	(4),
Dehum Cool	(5),
Dehum Heat	(6),
Warm Up Mode	(7)

}

BACne	t Prope	rties fo	or the VCM Con	troller
Parameter	Name	Object	Description	Limits
Application Software Version	AppVer	AI: 99	Current version of the software in the unit.	
Alarm Status	AlrmSts	AI: 1	Needed only in legacy application.	
Unit Mode	UnitMode	AI: 123	Needed only in legacy application.	
Control Status	CtrlSts	AI: 4	Current operational status.	
Control Temperature	CtrlTp	AI: 9	Current value of the control temperature sensor.	
Occupied/ Mode Enable Cooling Setpoint Mirror	ClSt	AI: 7	Occupied/ Mode Enable Cooling Setpoint Mirror.	
Duct Static Pressure	DuctPr	AI: 14	Current value of the duct static pressure sensor.	
Economizer Position	EcoPos	AI: 16	Current position of the economizer damper.	
External Relays 1-2	ExRlys12	AI: 111	Needed only in legacy application.	
External Relays 3-4	ExRlys34	AI: 112	Needed only in legacy application.	
Indoor Humidity	InRh	AI: 67	Current value of the indoor humidity sensor.	
Occupied/ Mode Enable Heating Setpoint Mirror	HtSt	AI: 31	Occupied/ Mode Enable Heating Setpoint Mirror.	
On Board Relays	OnRlys	AI: 44	Needed only in legacy application.	
Outdoor Air Humidity	OaRh	AI: 52	Current value of the outdoor humidity sensor.	
Outdoor Air Temperature	ОаТр	AI: 54	Current value of the outdoor temperature sensor.	
Outdoor Air Wetbulb	OaWtbl	AI: 55	Current calculated value of the outdoor wetbulb temperature.	
Relief Pressure	RfPr	AI: 62	Current value of the building pressure sensor.	
Return Air $CO_2$ Level	CO2Level	AI: 150	Current value of the $CO_2$ sensor.	
Return Air Temperature	RaTp	AI: 64	Current value of the return temperature sensor.	
Space Temperature	SpcTp	AI: 72	Current value of the space temperature sensor.	

BACnet	BACnet Properties for the VCM Controller					
Parameter	Name	Object	Description	Limits		
Supply Air Temperature	SaTp	AI: 83	Current value of the supply air temperature sensor.			
Temperature Demand	TpDmnd	AI: 84	Based on the comparison between the current Control Temperature and the Heating or Cooling Setpoint Temperatures. Does not work for supply air control.			
VFD Blower Fan	VfdBwPos	AI: 88	Current position of the VFD blow- er fan signal.			
VFD Relief Fan	VfdExPos	AI: 89	Current position of the VFD relief fan signal.			
Modulating Gas Valve Position	MdHt2Pos	AI: 38	Current position of MODGAS II modulating gas valve control.			
Reheat Value Position	Rt2Pos	AI: 60	Current position of MHGRV modulating hot gas reheat valve control.			
Alarm Group 1	AlrmGrp1	AI: 104	Needed only in legacy applica- tion.			
Alarm Group 2	AlrmGrp2	AI: 105	Needed only in legacy applica- tion.			
Alarm Group 3	AlrmGrp3	AI: 106	Needed only in legacy applica- tion.			
Dewpoint Setpoint Mirror	DptStM	AI: 110	Mirror of the DPtSt "read only."			
Indoor RH Setpoint Mirror	InRhStM	AI: 114	Mirror of the InRhSt "read only."			
Modulating Cool Position	MdClPos	AI: 115	Current position of the modulating cooling signal (Chilled water or digital compres- sor).			

<b>BACnet Properties for the VCM Controller</b>			ller	BACnet	Properti	es for	the VCM Co	ntro	ller		
Parameter	Name	Object	Description	Lin	nits	Parameter	Name	Object	Description	Lin	nits
Modulating Heat Position	MdHtPos	AI: 116	Current position of the modulating heating signal (hot water or SCR heat).			Minimum Outside Air Setpoint	MinEcoSt	AO: 151	This is the minimum position of the economizer in the occupied modes	1	100
Bypass Damper Position	ByPasDmp	AI: 153	Current position of the bypass damper signal.			Occupied/ Mode Enable	OcpClSt	AO: 42	If the control temperature rises one degree above	0	99
Return Damper Position	RaDmp	AI: 154	of the return damper signal.			Cooling Setpoint			this setpoint, the control will activate the		
Outdoor Air Dewpoint	OaDwpt	AI: 47	Current calcu- lated outdoor air dewpoint added on version 1.09.						If the control temperature is the Supply Air Sensor, then the		
Current Supply Air Setpoint	SaTpStM	AI: 82	Current SAT Cooling or Heat- ing setpoint if			Occupied/	OcnHtSt	AQ: 43	is always active.	0	99
			there is no reset source; Current calculated SAT setpoint with Reset Source.			Mode Enable Heating Setpoint	Ocpinst	AU. 45	temperature drops one degree below this setpoint, the control will	0	33
Coil Temperature	CoilTp	AI: 181	Current coil temperature reading added on version 1.09.						activate the heating demand. If the control		
Preheater Setpoint	PreHtSp	AO: 196	Low Outside Air Ambient Protection Setpoint	0	100				is the Supply Air Sensor, then there is no heat- ing demand.		
						Outdoor Air Sensor Offset	OaTpOst	AO: 53	If the Outdoor Temperature	-100	100
CO <sub>2</sub> Setpoint	CO2St	AO: 149	When the CO <sub>2</sub> level rises above the CO <sub>2</sub> Protection Limit Max Level, the Economizer's Minimum Posi- tion will begin to reset open	0	3000				Sensor is reading incorrectly, you can use this op- tion to enter an offset temperature to adjust the Sen- sor's Tempera- ture.		
			proportion- ally between the CO <sub>2</sub> Protection Limit Max Level Setpoint and the Reset Range			Relief Pressure Setpoint	RfPrSt	AO: 118	This is the target building pressure to be maintained by the VFD Relief signal.	-0.2	0.2
Static Pressure Setpoint	DuctPrSt	AO: 152	Setpoint. This is the target duct pressure to be maintained by the VFD blower signal.	0.01	3	Return Air Sensor Offset	RaTpOst	AO: 65	If the Return Temperature Sensor is read- ing incorrectly, you can use this option to enter an offset tem- perature to adjust	-100	100
									Temperature.		

# PT-Link II BACnet<sup>®</sup> Technical Guide

BACnet Properties for the VCM Controller					
Parameter	Name	Object	Description	Lim	its
Schedule Force	SchdFrc	AO: 66	0 = Auto/ Unoccupied Mode 1 = Forced On 2 = Forced Off	0	2
Space Sensor Offset	SpcTpOst	AO: 71	If the Space Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature.	-100	100
SAT/Reset Source Cooling Setpoint	SaClSt	AO: 77	Supply Air setpoint or Reset Source tar- get temperature in Cooling Mode.	40	80
SAT/Reset Source Heating Setpoint	SaHtSt	AO: 78	Supply Air setpoint or Reset Source tar- get temperature in Heating Mode.	40	200
Supply Air Sensor Offset	SaTpOst	AO: 80	If the Supply Air Temperature Sensor is reading incorrectly, you can use this option to enter an offset temperature to adjust the Sensor's Temperature.	-100	100
Unoccupied Cooling Offset	UnClOst	AO: 124	During the Unoccupied Mode of Operation, this Setpoint spreads the Occupied Cooling Setpoint out by a user adjustable amount. If you do not want Cooling to operate during the Unoccupied Mode, use the default setting of 30°F for these setpoints.	0	30
Unoccupied Heating Offset	UnHtOst	AO: 125	During the Unoccupied Mode of Operation, this Setpoint spreads the Occupied Heating Setpoint out by a user adjustable amount. If you do not want Heating to operate during the Unoccupied Mode, use the default setting of 30°F for these setpoints.	0	30

BACnet Properties for the VCM Controller					
Parameter	Name	Object	Description	Lim	nits
Dewpoint Setpoint	DptSt	AO: 13	If the outdoor dewpoint rises above this setpoint, the unit will activate the Dehumidification Demand.	35	80
Coil Temperature Setpoint	CoilTpSt	AO: 107	This is the coil suction temperature target during dehumidification mode. Produces dewpoint in the supply air approximately 10°F above this setpoint.	35	70
Indoor Humidity Setpoint	InRhSt	AO: 120	If the indoor humidity rises above this setpoint, the unit will activate the Dehumidification Demand.	0	100
Warm Up Setpoint	WmupSt	AO: 91	In a VAV application, upon entering the occupied mode, the Warm-up Demand will be activated if the return air temperature falls one degree below this setpoint.	50	90
Wet Bulb Setpoint	WtblSt	AO: 92	The economizer is enabled if the out- door temperature or wetbulb falls below this setpoint.	0	80
Bad Supply Air Sensor	SaTpAlm	BI: 2	Alarm that indicates a failure in the supply air sensor.		
CO <sub>2</sub> Sensor Installed	CO2Cfg	BI: 3	Status that indicates the $CO_2$ function has been configured.		
Cooling Demand	ClDmnd	BI: 5	Status that indicates a demand for cooling.		
Cooling Enabled	ClEnbl	BI: 6	Status that indicates mechanical cooling is enabled.		
Economizer Enabled	EcoEnbl	BI: 15	Status that indicates the economizer is enabled.		

BACnet Properties for the VCM Controller						
Parameter	Name	Object	Description	Limits		
Fan Start Up Delay	FanDly	BI: 25	Status that indicates the fan is commanded to run, but it is in the start up delay mode.			
Fan Proving Alarm	PofAlm	BI: 26	Alarm that indicates a failure in the flow of the VFD blower.			
Heating Demand	HtDmnd	BI: 29	Status that indicates a demand for heating.			
Heating Enabled	HtEnbl	BI: 30	Status that indicates that mechanical heating is enabled.			
High Supply Air Temperature Alarm	HiSaAlm	BI: 33	The Supply Air has risen above the Hi SAT Cutoff Setpoint. Heating stages begin to deac- tivate and the fan continues to run.			
Low Supply Air Temperature Alarm	LoSaAlm	BI: 37	The Supply Air has fallen below the Hi SAT Cutoff Setpoint and cooling stages will begin to deacti- vate. If the unit is in Economizer, Vent, or Heating Mode the Supply Fan will shut off.			
MODGAS II Connected	MdHt2Ins	BI: 39	Status that indicates the MODGAS II controller is connected.			
Proof of Flow Configured	PofCfg	BI: 57	Status that indicates the proof of flow function has been configured.			
REHEAT II Connected	Rt2Ins	BI: 58	Status that indicates the MHGRV con- trollers is connected to the system.			
Warm Up Mode Active	WmupD- mnd	BI: 90	Status that indicates the control is in the Warm-up mode.			
Mechanical Cooling Alarm	MchClAlm	BI: 94	Compressor Relays are enabled but the Supply Air Temperature has not fallen 5°F w/in a user-adjustable time period. This does not indicate compressors are active and will not shut the unit down.			

BACnet	BACnet Properties for the VCM Controller					
Parameter	Name	Object	Description	Limits		
Mechanical Heating Alarm	MchHtAlm	BI: 95	Heating Mode has been initiated but the Supply Air Temperature has not risen 5°F w/in a user-adjustable time period. This does not indicate heat stages are active and will not shut the unit down.			
Dirty Filter Detected	DrtFlAlm	BI: 96	Alarm that indicates the filters are dirty.			
Control Temperature Cool Failure	CtrlTpCF	BI: 108	This alarm is activated if the control temperature does not get within 5°F to the occupied cooling setpoint in an hour in the cooling mode. This alarm is not used in 100% outside air units or supply air control.			
Control Temperature Heat Failure	CtrlTpHF	BI: 109	This alarm is activated if the control temperature does not get within 5°F to the occupied heating setpoint in an hour in the heating mode. This alarm is not used in 100% outside air units or supply air control.			
Dehu- midification Demand	DehmDmnd	BI: 113	Status that indicates a demand for dehumidification.			
Outdoor Air Temperature Lost	OaTpAlm	BI: 117	Alarm that indicates a failure in the outdoor air temperature.			
Smoke Detected Alarm	SmokeAlm	BI: 119	Alarm that indicates the Smoke sensor has been activated.			
Space Temperature Sensor Lost	SpcTpAlm	BI: 101	Alarm that indicates a failure in the space temperature sensor.			
On Board Relay 1	OnRly1	BI: 127	Current status of relay 1.			
On Board Relay 2	OnRly2	BI: 128	Current status of relay 2.			
On Board Relay 3	OnRly3	BI: 129	Current status of relay 3.			
On Board Relay 4	OnRly4	BI: 130	Current status of relay 4.			

# **Appendix F - VCM BACnet Parameters**

BACnet Properties for the VCM Controller					
Parameter	Name	Object	Description	Limits	
On Board Relay 5	OnRly5	BI: 131	Current status of relay 5.		
Expansion Relay 1	ExRly1	BI: 133	Current status of relay 6.		
Expansion Relay 2	ExRly2	BI: 134	Current status of relay 7.		
Expansion Relay 3	ExRly3	BI: 135	Current status of relay 8.		
Expansion Relay 4	ExRly4	BI: 136	Current status of relay 9.		
Expansion Relay 5	ExRly5	BI: 137	Current status of relay 10.		
Expansion Relay 6	ExRly6	BI: 138	Current status of relay 11.		
Expansion Relay 7	ExRly7	BI: 139	Current status of relay 12.		
Expansion Relay 8	ExRly8	BI: 140	Current status of relay 13.		
Expansion Relay 9	ExRly9	BI: 141	Current status of relay 14.		
Expansion Relay 10	ExRly10	BI: 142	Current status of relay 15.		
Expansion Relay 11	ExRly11	BI: 143	Current status of relay 16.		
Expansion Relay 12	ExRly12	BI: 144	Current status of relay 17.		
Expansion Relay 13	ExRly13	BI: 145	Current status of relay 18.		
Expansion Relay 14	ExRly14	BI: 146	Current status of relay 19.		
Expansion Relay 15	ExRly15	BI: 147	Current status of relay 20.		
Expansion Relay 16	ExRly16	BI: 148	Current status of relay 21.		

### VCM PT-Link-BACnet® Property Identifier:

The PT-Link-BACnet<sup>®</sup> Link amends the following property identity to the BACnet<sup>®</sup> property identifier.

### **BACNETPropertyIdentifier :**

#### WattBACNETScheduleForce ::= ENUMERATED {

NormalOperation	(0),
ForceOccupied	(1),
ForceUnoccupied	(2)
}	

VcmUnitMode ::= ENUMERATED {	
Unoccupied	(0),
RemoteContactOccupied	(1),
NormalScheduleOccupied	(2),
PushButtonOrZoneOverride	(3),
HolidayModeActive	(4),
UnoccupiedZoneDemand	(5),
RemoteScheduleOverride	(6),
CurrentOutputForceMode	(7),
SATHighOrLowCutOff	(8),
CO2OverrideInProgress	(9),
PurgeModeActive	(10)
}	

VcmControlStatusBits ::= BIT STRING {

Cool Demand	(0),
Heat Demand	(1),
DehumidificationMode	(2),
Cooling Enabled	(3),
Heating Enabled	(4),
Economizer Enabled	(5),
Fan Start-up Delay	(6),
Warm-up Mode Active	(7),
Fan Proving	(8),
RH Priority	(9),
CarbonDioxideSensorPresent	(10),
ModGasIIConnected	(11),
ReheatIIConnected	(12)
1	

### }

### VcmOnBoardRelaysBits ::= BIT STRING {

OnBoardRelay1	(0),
OnBoardRelay2	(1),
OnBoardRelay3	(2),
OnBoardRelay4	(3),
OnBoardRelay5	(4)
}	

VcmExternal Relays1-2Bits ::= BIT STRING	{
ExpansionBoard1Relay1	(0),
ExpansionBoard1Relay2	(1),
ExpansionBoard1Relay3	(2),
ExpansionBoard1Relay4	(3),
ExpansionBoard2Relay1	(4),
ExpansionBoard2Relay2	(5),
ExpansionBoard2Relay3	(6),
ExpansionBoard2Relay4	(7)
}	
VcmExternal Relays2-4Bits::= BIT STRING	{
ExpansionBoard3Relay1	(0),
ExpansionBoard3Relay2	(1),
ExpansionBoard3Relay3	(2),
ExpansionBoard3Relay4	(3),
ExpansionBoard4Relay1	(4),
ExpansionBoard4Relay2	(5),
ExpansionBoard4Relay3	(6),
ExpansionBoard4Relay4	(7)
}	
VcmAlarmStatusBits ::= BIT STRING {	
Alarm Group1	(0),
Alarm Group2	(1),
Alarm Group3	(2)
}	

VcmAlarmGroup1Bits ::= BIT STRING {	
SupplyTempSensorFailure	(0),
LostOutdoorTempSensorSignal	(1),
LostSpaceTempSensorSignal	(2)
}	
VcmAlarmGroup2Bits ::= BIT STRING {	
MechanicalCoolingAlarm	(0),
MechanicalHeatingAlarm	(1),
FanProvingAlarm	(2),
DirtyFilterDetected	(3),
SmokeDetected	(4)
}	
VcmAlarmGroup3Bits ::= BIT STRING {	
LowSupplyAirTempAlarm	(0),
HighSupplyAirTempAlarm	(1),
LowControlTempAlarm	(2),
HighControlTempAlarm	(3)
}	



Form: OR-PTLNK-II-BACNET-TGD-01D All rights reserved.

WattMaster Controls, Inc. • 8500 NW River Park Drive • Parkville, MO • 64152 Phone (816) 505-1100

Printed in the USA

www.orioncontrols.com

August 2011 Copyright 2011

Fax (816) 505-1101